Original		Rechange		Original	Rechange
	Power		Power		
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
SEARCH MODE -/--	-/--/Search Mode	GUIDE EPG	Guide / EPG / -/--		
0	0	0	0		
ENTER	Enter	OK	OK		

Original		Rechange	
	Power		Power
AV MUTING	AV Muting	DIMMER MUTE	Mute / Dimmer
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
PREV	I<</Prev	PRESET-	I<< / Preset-
NEXT	>>I / Next	PRESET+	>>I / Preset+
TITLE	Title	TITLE SOUND	Sound / Title
AUDIO CHANGE	Audio Change	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE ON/OFF	Subtitle On/Of	EQ SUBTITLE	Subtitle / EQ
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
WIDE MODE	Wide Mode	SIZE ZOOM	Zoom / Size
TIME	Time	TIMER SLEEP	Sleep / Timer
TV/DVD	Tv/DVD	PROGRAM TV/ RADIO	TV/Radio /
DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top Menu

Original		Rechange	
SET UP	Set Up	OPT-TOOLS SETUP	Setup / OPT /
TV/VIDEO	Tv/Video	RDS AV INPUT	AV / Input / RDS
	Up		Up
ANGLE CHANGE	Angle Change	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL +	Vol +	VOL +	Vol +
DNR	DNR	LIST SMART	Smart / List
PROG +	Prog+	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Prog-	CH PAGE -	CH- / Page-
1	1	TV 1	1

Original		Rechange		Original	Rechange
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
SEARCH MODE -/--	-/--/Search Mode	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
A↔B	A↔B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random		
SUBTITLE CHANGE	Subtitle Change	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ		
PROGRAM	Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program		
AV VOL -	AV Vol -	SHIFT +	Shift + Left		
AV VOL +	AV Vol +	SHIFT +	Shift + Right		