Mandis shop

RM-SEP30

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | I<<<< | I<< / Preset- |
| Volume+ | Vol + | >>>>I | >>I / Preset+ |
| Music Menu | Menu / Home | Clock/Timer/Sleep Set | Sleep / Timer |
| Mega Bass | Sound / Title | Timer On/Off | Fav / Marker / PC |
| Volume- | Vol - | Repeat | Green / APP / Repeat |
| Tape | 5 | | |
| CD/Remain | 3 | | |
| Tuner/Band | 6 | | |
| Preset + | SHIFT + >>I / Preset+ | | |
| Tuning/Clock/Timer + | >> / Tune+ | | |
| Tuner | OK | | |
| Preset - | SHIFT + I<< / Preset- | | |
| Tuning/Clock/Timer - | << / Tune- | | |
| Shuffle | Smart / List | | |
| Play | Play / Slow | | |
| Pause | Pause / Step / Freeze | | |
| Stop | Stop / Hold | | |

https://tout-telecomande.fr/fr/Sony/10821-Telecommande-remplacement-pour-Sony-RM-SEP30-146271.html