Original		Rechange		Original		Rechange	
POWER	Power		Power	GOTO	Goto	GOTO TEXT	Text / Goto
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround	TITLE	Title	TITLE SOUND	Sound / Title
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		Up		Up
1	1	TV 1	1	MENU	Menu	HOME MENU	Menu / Home
2	2	DVD 2	2		Left		Left
3	3	CD - STB 3	3	ENTER/	Enter / Play	SLOW	Play / Slow
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear	ENTER/	Enter / Play	OK	OK
4	4	VIDEO 4	4		Right		Right
5	5	TAPE 5	5	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
6	6	TUNER 6	6		Down		Down
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /	T.E.	T. E.	LIST SMART	Smart / List
7	7	AUX - HDD 7	7	ZOOM	Zoom	SIZE ZOOM	Zoom / Size
8	8	USB 8	8	SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
9	9	BLUETOOTH 9	9	AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
DISPLAY	Display	MEDIA DISPLAY	Display / Media	ANGLE	Angle	ANGLE INFO	Info / Angle
0	0	HDMI - SAT 0	0	VOL	Vol +	VOL	Vol +
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--	P/N	P/N	TOP MENU D.MENU	D.Menu / Top

Original		Rechange		Original		Rechange
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat			
A-B	A-B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat			
VOL	Vol -	VOL	Vol -			
REV	<< REV	TUNE-	<< / Tune-			
FWD	>> FWD	TUNE+	>> / Tune+			
PREV	I<< Prev	PRESET-	I<< / Preset-			
NEXT	>>I Next	PRESET+	>>I / Preset+			
STOP	Stop	HOLD	Stop / Hold			
RESUME	Resume	CH PAGE +	CH+ / Page+			
PAUSE/STEP	Pause / Step	STEP-FREEZE	Pause / Step / Freeze			
SLOW	Slow	SHIFT + SLOW	Shift + Play /			
SLOW	Slow	CH PAGE -	CH- / Page-			
SHUFFLE	Shuffle	Prime Video / RANDOM	Blue / Prime Video / Random			