| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| OPEN/CLOSE | Open/Close | ZOOM | Eject |
| PRESET/ALBUM | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Ok | OK | Ok |
| | >>I | | >>I |
| | I << | | I << |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| MENU | Stop | | Stop |
| MENU | Menu | TOP MENU MENU | Menu |
| DISPLAY RDS | RDS/Display | DISPLAY INFO | Info |
| VOL + | Vol + | + VOL | Vol + |
| – VOL | Vol - | VOL – | Vol - |
| | Mute | MUTE | Mute |

| Original | | Rechange | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| DBB | DBB | APP MEDIA | Media |
| DSC | DSC | HOME SMART | Smart |
| PROG/ CLOCK SET | Prog/Clock Set | SETTINGS OPT | Options |
| REPEAT/ SHUFFLE | Repeat/Shuffle | REPEAT TEXT | Text |
| SLEEP/ TIMER | Sleep/Timer | PROG SLEEP | Sleep |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| OPEN/CLOSE | Open/Close | ZOOM | Eject |
| PRESET/ALBUM | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Ok | OK | Ok |
| | >>I | | >>I |
| | I << | | I << |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| MENU | Stop | | Stop |
| MENU | Menu | TOP MENU MENU | Menu |
| DISPLAY RDS | RDS/Display | DISPLAY INFO | Info |
| VOL + | Vol + | + VOL | Vol + |
| – VOL | Vol - | VOL – | Vol - |
| | Mute | MUTE | Mute |

| Original | | Rechange | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| PROG/ CLOCK SET | Prog/Clock Set | SETTINGS OPT | Options |
| REPEAT/ SHUFFLE | Repeat/Shuffle | REPEAT TEXT | Text |
| DBB | DBB | APP MEDIA | Media |
| DSC | DSC | HOME SMART | Smart |
| SLEEP/ TIMER | Sleep/Timer | PROG SLEEP | Sleep |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| OPEN/CLOSE | Open/Close | ZOOM | Eject |
| PRESET/ALBUM | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Ok | OK | Ok |
| | >>I | | >>I |
| | I << | | I << |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| MENU | Stop | | Stop |
| MENU | Menu | TOP MENU MENU | Menu |
| DISPLAY RDS | RDS/Display | DISPLAY INFO | Info |
| VOL + | Vol + | + VOL | Vol + |
| – VOL | Vol - | VOL – | Vol - |
| | Mute | MUTE | Mute |

| Original | | Rechange | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| PROG/ CLOCK SET | Prog/Clock Set | SETTINGS OPT | Options |
| DSC | DSC | HOME SMART | Smart |
| DBB | DBB | APP MEDIA | Media |
| SLEEP/ TIMER | Sleep/Timer | PROG SLEEP | Sleep |
| REPEAT/ SHUFFLE | Repeat/Shuffle | REPEAT TEXT | Text |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| OPEN/CLOSE | Open/Close | ZOOM | Eject |
| PRESET/ALBUM | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Ok | OK | Ok |
| | >>I | | >>I |
| | I << | | I << |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| MENU | Stop | | Stop |
| MENU | Menu | TOP MENU MENU | Menu |
| DISPLAY RDS | RDS/Display | DISPLAY INFO | Info |
| VOL + | Vol + | + VOL | Vol + |
| – VOL | Vol - | VOL – | Vol - |
| | Mute | MUTE | Mute |

| Original | | Rechange | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| REPEAT/ SHUFFLE | Repeat/Shuffle | REPEAT TEXT | Text |
| DBB | DBB | APP MEDIA | Media |
| DSC | DSC | HOME SMART | Smart |
| SLEEP/ TIMER | Sleep/Timer | PROG SLEEP | Sleep |
| PROG/ CLOCK SET | Prog/Clock Set | SETTINGS OPT | Options |