Mandis shop

Sony RM-SC50

Original		Rechange	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I / ⏻	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SELECT	Clock Timer	TOP MENU D.MENU	D.Menu / Top
SET	Clock Timer Set	HOME MENU	Menu / Home
TUNER MEMORY	Tuner Memory		Left
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode		Right
REPEAT/ FM MODE	Repeat/FM	APP REPEAT	Green / APP / Repeat
REPEAT/ FM MODE	Repeat/FM		Down
TAPE	Tape	TAPE 5	5
CD	CD	CD - STB 3	3
TUNER BAND	Band/Tuner		Up
TUNER BAND	Band/Tuner	TUNER 6	6
FUNCTION	Function	LIST SMART	Smart / List
–	I<<</-	PRESET-	I<< / Preset-
+	>>I/+	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Original		Rechange	
	>>	TUNE+	>> / Tune+
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOLUME +	Vol+	+ VOL	Vol+
ENTER	Enter	OK	OK
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
VOLUME –	Vol-	VOL –	Vol-
DISC SKIP	Disc Skip	SURROUND	Eject / Surround
–	Folder-	CH PAGE –	CH- / Page-
+	Folder+	+ CH PAGE	CH+ / Page+

https://tout-telecommandes.fr/fr/Sony/1055954-6103-telecommande-de-remplacement-pour-Sony-RM-SC-50-A1108433B.html