Original		Rechange	
	Power		Power
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	Rec	REC MODE	Rec
	<<		<<
	>>		>>
SOURCES	Sources	TIMER AV	AV
TV EXIT	Tv/Exit	CLEAR EXIT	Exit
	Tv Guide	-/-- GUIDE	Guide
	*/Top Picks	FAV PRE-CH	Pre Ch
NETFLIX	Netflix	APP MEDIA	Media
	☼	TOP MENU MENU	Menu
	[ ]]/Folders	SOUND DUAL	Dual
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow

Original		Rechange	
	Blue	D	Blue
INFO	Info	DISPLAY INFO	Info
	[.:]	ECO 3D	3D
OPTIONS	Options	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
	Search	SEARCH TV/R	TV/R
HOME	Home	HOME SMART	Smart
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Mute	MUTE	Mute
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	CH+	+ CH	Ch +
	CH-	CH −	Ch -

Original		Rechange	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SUBTITLE	Subt i t l e	AD SUBT	Subt
TEXT	Text	REPEAT TEXT	Text

Original	Rechange