Mandis shop

# Philips 996580004176

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| COAX | Coax | HOME SMART | Smart |
| OPT | OPT | SETTINGS OPT | Options |
| AUDIO IN | Audio In | SOUND DUAL | Dual |
| | Blutooth | | Up |
| USB | USB | | Down |
| AUX | AUX | APP MEDIA | Media |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | Play/Pause | OK | Ok |
| | >I | | >>I |
| | >I | | Right |
| | I< | | I<< |
| | I< | | Left |
| VOL | Vol+ | VOL | Vol + |
| VOL | Vol- | VOL | Vol - |
| | Mute | MUTE | Mute |

| Original | | Rechange | |
|---|---|---|---|
| AUDIO SYNC | Audio Sync+ | CH | Ch + |
| AUDIO SYNC | Audio Sync- | CH | Ch - |
| BASS | Bass+ | 1 | 1 |
| BASS | Bass- | 4 | 4 |
| SURR | Surr | 2 | 2 |
| NIGHT | Night | 5 | 5 |
| TREBLE | Treble+ | 3 | 3 |
| TREBLE | Treble- | 6 | 6 |

https://tout-telecommandes.fr/fr/Philips/1056002-65454-telecommande-de-remplacement-pour-Philips-996580004176.html