Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
MUTE	Mute	MUTE	Mute
MODE	Mode	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--		SHIFT + -/-- GUIDE	Shift + Guide
BACK	Back	RETURN BACK	Back
NICAM/A2	Nicam/A2	SOUND DUAL	Dual

Original		Rechange	
TXT/MIX	TXT/MIX	REPEAT TEXT	Text
TXT/MIX	Play	PLAY MODE	Play
TXT/MIX	Pause		Pause
CANCEL	Stop		Stop
REC	Rec	REC MODE	Rec
INDEX	>>/Index		>>
HOLD	<<</Hold		<<
SIZE	I<<		I<<
REVEAL	>>I		>>I
CANCEL	Cancel	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
DTV/RADIO	DTV/Radio	SEARCH TV/R	TV/R
VOL+	Vol+	+ VOL	Vol +
VOL-	Vol-	VOL –	Vol -
	Up		Up
	Down		Down
	Right		Right

Original		Rechange	
	Left		Left
ENTER	Enter	OK	Ok
CH+	CH+	+ CH	Ch +
CH-	CH-	CH −	Ch -
FAV	FAV	FAV PRE-CH	Pre Ch
EPG	EPG	GUIDE	Guide
INFO	Info	DISPLAY INFO	Info
LIST	List	DISC NAV LIST	List
RED	Red	A	Red
GREEN	Green	B	Green
YELLOW	Yellow	C	Yellow
BLUE	Blue	D	Blue
SIZE	Size	PICTURE FORMAT	Format
REVEAL	Reveal	ECO 3D	3D
SUBTITLE	Subtitle	AD SUBT	Subt
SUBPAGE	Subpage	TIMER AV	AV
FAV+	FAV+	SHIFT + + CH	Shift + Ch +

Original		Rechange	
FAV-	FAV-	SHIFT + CH −	Shift + Ch -

Original	Rechange	Original	Rechange
Power	Power	Vol+	Vol +
Mute	Mute	Vol-	Vol -
[I]/Menu	Menu	CH+	Ch +
Exit	Exit	CH-	Ch -
Source	AV	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK	Ok
5	5	Recall	Back
6	6	Info	Info
7	7	EPG	Guide
8	8	Freeze	Options
9	9	Red	Red
0	0	Green	Green
Subtitle	Subt	Yellow	Yellow
Text	Text	Blue	Blue

Original	Rechange		Original	Rechange
Audio	SOUND DUAL	Dual		
I<</[≡+]		I<<		
>>I/[≡..]		>>I		
[≡i]	HOME SMART	Smart		
Play	PLAY MODE	Play		
Pause		Pause		
Stop		Stop		
REP/Rec	REC MODE	Rec		
<</[≡o]		<<		
>>/[≡?]		>>		
FAV	FAV PRE-CH	Pre Ch		