Original		Rechange	
	Power Tuner		Power
	Mute	MUTE	Mute
	1 Tuner	1	1
	2 Tuner	2	2
	3 Tuner	3	3
	4 Tuner	4	4
	5 Tuner	5	5
	6 Tuner	6	6
	7 Tuner	7	7
	8 Tuner	8	8
	9 Tuner	9	9
	0 Tuner	0	0
CINEMA GO	Cinema Go	GUIDE	Guide
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Play Tuner / Phono/ Cabl	PLAY MODE	Play
	Stop Tuner / Phono/ Cabl e Box		Stop

Original		Rechange	
LOUDNESS	Loudness	AD SUBT	Subt
SUBW. ON/OFF	Subw. On/Off	HOME SMART	Smart
VIRTUAL MODE	Mode/Virtual	SETTINGS OPT	Options
NIGHT	Night	ECO 3D	3D
SURROUND ON/OFF	Surround On/Off	APP MEDIA	Media
REAR +	Channel / Rear +	+ CH	Ch +
CHANNEL -	Channel / Rear -	CH -	Ch -
SURROUND MODE	Surround Mode	SEARCH TV/R	TV/R
TEST TONE	Test Tone	CLEAR EXIT	Exit
SUB WOOFER +	Sub woofer +	B	Green
SUB WOOFER -	Sub Woofer -	A	Red
	Right Tuner		Right
	Up Tuner		Up
	Down Tuner		Down
	Left Tuner		Left
OK	OK Tuner	OK	Ok
GUIDE MENU	Menu / Guide	TOP MENU MENU	Menu

Tuner

Original		Rechange		Original	Rechange
NEWS/TA	i / News/ TA	DISPLAY INFO	Info		
CHANNE	I < Channel / Track		I <<		
L/TRACK	Channel / Track >I Tuner		>>I		
FR.D.	Pause/ FR. D.		Pause		
TUNER	Tuner	SHIFT + HOME SMART	Shift + Smart		
PHONO	Phono	SHIFT + APP MEDIA	Shift + Media		
	Power Phono	SHIFT +	Shift + Power		

Original	Rechange
Power Tv	Power
TV	Blue
Mute Tv	Mute
1 Tv	1
2 Tv	2
3 Tv	3
4 Tv	4
5 Tv	5
6 Tv	6
7 Tv	7
8 Tv	8
9 Tv	9
0 Tv	0
Menu/Guide Tv	Menu
OK Tv	Ok
Up Tv	Up
Down Tv	Down

Original	Rechange
Right Tv	Right
Left Tv	Left
Vol + Tv/CD	Vol +
Vol - Tv/CD	Vol -
Play Tv	Play
Stop Tv	Stop
i/News/TA Tv	Info
I< Channel/Track	I <<
Channel/Track >I	>>I
Power CD	Shift + Power
CD	Yellow
Mute CD	Shift + Mute
1 CD	Shift + 1
2 CD	Shift + 2
3 CD	Shift + 3
4 CD	Shift + 4
5 CD	Shift + 5

Original		Rechange		Original	Rechange
6	6 CD	SHIFT + 6	Shift + 6		
7	7 CD	SHIFT + 7	Shift + 7		
8	8 CD	SHIFT + 8	Shift + 8		
9	9 CD	SHIFT + 9	Shift + 9		
0	0 CD	SHIFT + 0	Shift + 0		
	Up CD	SHIFT + ▲	Shift + Up		
	Down CD	SHIFT + ▼	Shift + Down		
	Right CD	SHIFT + ▶	Shift + Right		
	Left CD	SHIFT + ◀	Shift + Left		
i NEWS/TA	i / News/TA CD	SHIFT + DISPLAY INFO	Shift + Info		
■	Stop CD	SHIFT + ■	Shift + Stop		
▶	Play CD	SHIFT + PLAY MODE ▶	Shift + Play		
CHANNE ⏮	I < CD	«	<<		
E/TRACK ⏭	>I CD	»	>>		
FR.D. ⏸	Pause/FR. D. CD	⏸	Pause		
CANCEL	: >/Cancel CD	CLEAR EXIT	Exit		
DVD DISC	Disc/DVD CD	HOME SMART	Smart		

Original		Rechange	
	Power SAT		Power
SAT	SAT	C	Yellow
1	1 SAT	1	1
2	2 SAT	2	2
3	3 SAT	3	3
4	4 SAT	4	4
5	5 SAT	5	5
6	6 SAT	6	6
7	7 SAT	7	7
8	8 SAT	8	8
9	9 SAT	9	9
0	0 SAT	0	0
MUTE	Mute SAT	MUTE	Mute
+	Vol + SAT/DVD	+ VOL	Vol +
–	Vol - SAT/DVD	VOL –	Vol -
	Play SAT	PLAY MODE	Play
	Stop SAT		Stop

Original		Rechange	
NEWS/TA	i / News/TA SAT	DISPLAY INFO	Info
GUIDE MENU	Menu/Guide	TOP MENU MENU	Menu
OK	OK SAT	OK	Ok
	Up SAT		Up
	Down SAT		Down
	Right SAT		Right
	Left SAT		Left
CHANNE	I< Channel/Track SAT		I<<
L/TRACK	Channel/Track >I SAT		>>I
CANCEL	:>/Cancel SAT	CLEAR EXIT	Exit
INDEX T·C	T·C/Index SAT	RETURN BACK	Back
	Power DVD	SHIFT +	Shift + Power
DVD	DVD	D	Blue
1	1 DVD	SHIFT + 1	Shift + 1
2	2 DVD	SHIFT + 2	Shift + 2
3	3 DVD	SHIFT + 3	Shift + 3
4	4 DVD	SHIFT + 4	Shift + 4

Original		Rechange	
5	5 DVD	SHIFT + 5	Shift + 5
6	6 DVD	SHIFT + 6	Shift + 6
7	7 DVD	SHIFT + 7	Shift + 7
8	8 DVD	SHIFT + 8	Shift + 8
9	9 DVD	SHIFT + 9	Shift + 9
0	0 DVD	SHIFT + 0	Shift + 0
GUIDE MENU	Menu/Guide	SHIFT + TOP MENU MENU	Shift + Menu
OK	OK DVD	SHIFT + OK	Shift + Ok
	Up DVD	SHIFT + ▲	Shift + Up
	Down DVD	SHIFT + ▼	Shift + Down
	Right DVD	SHIFT + ▶	Shift + Right
	Left DVD	SHIFT + ◀	Shift + Left
▶	Play DVD	SHIFT + PLAY MODE ▶	Shift + Play
■	Stop DVD	SHIFT + ■	Shift + Stop
i NEWS/TA	i/News/TA DVD	SHIFT + DISPLAY INFO	Shift + Info
CHANNEL ⏮	I< Channel/Track DVD	«	<<
TRACK ⏭	Channel/Track >I DVD	»	>>

Original		Rechange	
DVD DISC	Disc DVD	HOME SMART	Smart
REC AUDIO	Audio DVD	SOUND DUAL	Dual
CANCEL	:>/Cancel DVD	SHIFT + CLEAR EXIT	Shift + Exit
FR.D. ⏸	Pause/FR.D.	⏸	Pause
INDEX T-C	T·C/Index DVD	SHIFT + RETURN BACK	Shift + Back

Original		Rechange	
	Power VCR		Power
VCR	VCR	C	Yellow
MUTE	Mute VCR	MUTE	Mute
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
GUIDE MENU	Menu/Guide	TOP MENU MENU	Menu
	Up VCR		Up
OK	OK VCR	OK	Ok
	Down VCR		Down

Original		Rechange	
	Right VCR		Right
	Left VCR		Left
	Vol + VCR	+ VOL	Vol +
	Vol - VCR	VOL −	Vol -
	Play VCR	PLAY MODE	Play
	Stop VCR		Stop
CHANNE	I< Channel/Track VCR		I <<
L/TRACK	Channel/Track >I VCR		>>I
REC AUDIO	Rec VCR	REC MODE	Rec
CANCEL	:>/Cancel VCR	CLEAR EXIT	Exit
FR.D.	Pause/FR.D VCR		Pause
INDEX T-C	T·C/Index VCR	RETURN BACK	Back
	Power	SHIFT +	Shift + Power
CDR/TAPE	CDR/Tape	D	Blue
1	1 CDR/Tape	SHIFT + 1	Shift + 1
2	2 CDR/Tape	SHIFT + 2	Shift + 2
3	3 CDR/Tape	SHIFT + 3	Shift + 3

Original	Rechange	Original	Rechange
4 CDR/Tape	SHIFT + 4 Shift + 4	DVD DISC Disc CDR/Tape	HOME SMART Smart
5 CDR/Tape	SHIFT + 5 Shift + 5		
6 CDR/Tape	SHIFT + 6 Shift + 6		
7 CDR/Tape	SHIFT + 7 Shift + 7		
8 CDR/Tape	SHIFT + 8 Shift + 8		
9 CDR/Tape	SHIFT + 9 Shift + 9		
0 CDR/Tape	SHIFT + 0 Shift + 0		
Up CDR/Tape	SHIFT + ▲ Shift + Up		
Down CDR/Tape	SHIFT + ▼ Shift + Down		
Right CDR/Tape	SHIFT + ▶ Shift + Right		
Left CDR/Tape	SHIFT + ◀ Shift + Left		
i / News/TA	DISPLAY INFO Info		
I< Channel / Track CDR/Tape	SHIFT + I<< Shift + I<<		
Channel / Track >I CDR/Tape	SHIFT + >>I Shift + >>I		
Rec CDR/Tape	SHIFT + REC MODE Shift + Rec		
: >/ Cancel	SHIFT + CLEAR EXIT Shift + Exit		
Pause/FR. D. CDR/Tape	SHIFT + II Shift + Pause		