Original	Rechange
Mute	Mute / Dimmer
Power	Power
TV	Shift + 1
TV	Shift + Red / Netflix /
REC	Shift + Green / APP /
SP	Shift + Yellow / YouTube /
AUDIO	Audio / Lang I/II
AUDIO	Shift + Blue / Prime
Timer/IN-Mode	Sleep / Timer
>[ ]< / 5/7CH	Smart / List
Sound	Sound / Title
1	1
2	2
3	3
4	4
5	5
6	6

Original	Rechange
7	7
8	8
9	9
0/AV	0
0/AV	AV / Input / RDS
EPG/Bass	Guide / EPG / -/--
Media/Surr	Display / Media
Media/Surr	Eject / Surround
PIP/AUX	Picture / Format
PIP/AUX	Shift + 7
Text	Text / Goto
Menu	Menu / Home
End	Exit / Cancel / Clear
Info	Info / Angle
Vol +	Vol +
Up	Up
P+	CH+ / Page+

Original		Rechange		Original	Rechange
	Left		Left		
OK	OK	OK	OK		
	Right		Right		
-V	Vol -	VOL	Vol -		
	Down		Down		
P-	P-	CH PAGE	CH- / Page-		
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search		
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat		
SHOW	Yellow/Show	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
OFF	Blue/Off	Prime Video RANDOM	Blue / Prime Video / Random		
TUNE-	<<</Tune-	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
TUNE+	>>/Tune+	TUNE+	>> / Tune+		
MEMORY	Rec/Memory	REC MODE	Rec / Rec Mode		
II	Pause	STEP-FREEZE II	Pause / Step / Freeze		
ASP	Stop/ASP	HOLD	Stop / Hold		

Original		Rechange	
Power		Power	
TV		SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
TV		SHIFT + TV 1	Shift + 1
REC		SHIFT + APP REPEAT	Shift + Green / APP /
SP		SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
AUDIO		LANG I/II AUDIO	Audio / Lang I/II
IN-MODE	Timer/IN-Mode	TIMER SLEEP	Sleep / Timer
5/7CH	>[ ]</5/7CH	LIST SMART	Smart / List
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD-STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX-HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9

Original		Rechange	
0/AV		HDMI-SAT 0	0
0/AV		RDS AV INPUT	AV / Input / RDS
EPG/Bass		-/-- GUIDE EPG	Guide / EPG / -/--
Media/Surr		MEDIA DISPLAY	Display / Media
Media/Surr		SURROUND	Eject / Surround
PIP/AUX		FORMAT PICTURE	Picture / Format
PIP/AUX		SHIFT + AUX-HDD 7	Shift + 7
Text		GOTO TEXT	Text / Goto
Menu		HOME MENU	Menu / Home
End		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Info		ANGLE INFO	Info / Angle
Up			Up
P+		CH+ PAGE	CH+ / Page+
Left			Left
OK		OK	OK
Right			Right
Down			Down

Original	Rechange	Original	Rechange
P-	CH- / Page-		
Red/ Music	Red / Netflix / Search		
Green/ Movie	Green / APP / Repeat		
Yellow/ Show	Yellow / YouTube / Repeat		
Blue/ Off	Blue / Prime Video / Random		
<</ Tune-	<< / Tune-		
Play	Play / Slow		
>>/ Tune+	>> / Tune+		
Rec/ Memory	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop/ ASP	Stop / Hold		

Original	Rechange
Mute	Mute / Dimmer
Power	Power
TV	Shift + Red / Netflix /
REC	Shift + Blue / Prime
SP	Shift + Yellow / YouTube /
AUDIO	Shift + Green / APP /
AUDIO	Audio / Lang I/II
Timer/IN-Mode	Sleep / Timer
>[ ]</5/7/CH (1)	Smart / List
>[ ]</5/7/CH (2)	Shift + Smart / List
Sound	Sound / Title
Sound1	1
Sound2	2
Sound3	3
Sound4	4
EPG/Bass (1)	Guide / EPG / -/--
EPG/Bass (2)	6

Original	Rechange
EPG/Bass (3)	7
EPG/Bass (1)	5
Media/Surr	Display / Media
Media/Surr	Eject / Surround
PIP/AUX (1)	Shift + 1
PIP/AUX (2)	Shift + 2
PIP/AUX (3)	Shift + 3
PIP/AUX (4)	Shift + 4
PIP/AUX (5)	Shift + 5
PIP/AUX (6)	Shift + 6
PIP/AUX (7)	Shift + 7
Text	Text / Goto
Menu	Menu / Home
End	Exit / Cancel / Clear
Info	Info / Angle
Vol +	Vol +
Up	Up

Original		Rechange		Original	Rechange
	Left		Left		
OK	OK	OK	OK		
	Right		Right		
-V	Vol -	VOL	Vol -		
	Down		Down		
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search		
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat		
SHOW	Yellow/Show	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
OFF	Blue/Off	Prime Video RANDOM	Blue / Prime Video / Random		

Original		Rechange	
	Power		Power
	TV	SHIFT +	NETFLIX SEARCH: Shift + Red / Netflix /
	TV	SHIFT +	TV 1: Shift + 1
	REC	SHIFT +	APP REPEAT: Shift + Green / APP /
	SP	SHIFT +	YouTube REPEAT A-B: Shift + Yellow / YouTube /
	AUDIO		LANG I/II AUDIO: Audio / Lang I/II
	AUDIO	SHIFT +	Prime Video RANDOM: Shift + Blue / Prime
	IN-MODE Timer/IN-Mode		TIMER SLEEP: Sleep / Timer
	5/7CH >[ ]</5/7/CH		LIST SMART: Smart / List
	1		TV 1: 1
	2		DVD 2: 2
	3		CD-STB 3: 3
	4		VIDEO 4: 4
	5		TAPE 5: 5
	6		TUNER 6: 6
	7		AUX-HDD 7: 7
	8		USB 8: 8

Original		Rechange	
	9		BLUETOOTH 9: 9
	0/AV		RDS AV INPUT: AV / Input / RDS
	0/AV		HDMI-SAT 0: 0
	EPG/Bass		-/-- GUIDE EPG: Guide / EPG / -/--
	Media/Surr		MEDIA DISPLAY: Display / Media
	Media/Surr		SURROUND: Eject / Surround
	PIP/AUX		FORMAT PICTURE: Picture / Format
	PIP/AUX	SHIFT +	AUX-HDD 7: Shift + 7
	Text		GOTO TEXT: Text / Goto
	Menu		HOME MENU: Menu / Home
	End		CLEAR EXIT CANCEL: Exit / Cancel / Clear
	Info		ANGLE INFO: Info / Angle
	Up		Up
	P+		CH+ PAGE: CH+ / Page+
	Left		Left
	OK		OK
	Right		Right

Original		Rechange		Original	Rechange
	Down		Down		
	P-	CH PAGE	CH- / Page-		
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search		
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat		
SHOW	Yellow/Show	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
OFF	Blue/off	Prime Video RANDOM	Blue / Prime Video / Random		
TUNE-	<<</Tune-	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
TUNE+	>>/Tune+	TUNE+	>> / Tune+		
MEMORY	Rec/Memory	REC MODE	Rec / Rec Mode		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
ASP	Stop/ASP	HOLD	Stop / Hold		