Original		Rechange	
STANDBY	Standby		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Rechange	
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
▲	Up	▲	Up
◀	Left	◀	Left
OK	Ok	OK	OK
▶	Right	▶	Right
MENU	Menu	HOME MENU	Menu / Home
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
+ VOL	Vol +	+ VOL	Vol +
EPG	Epg	-/-- GUIDE EPG	Guide / EPG / -/--
+ CH	Ch+	+ CH PAGE	CH+ / Page+
VOL —	Vol -	VOL —	Vol -
MEDIA	Media	SHIFT + MEDIA DISPLAY	Shift + Display / Media
CH —	Ch-	CH PAGE —	CH- / Page-
REC	Rec	REC MODE	Rec / Rec Mode

Original		Rechange	
T.SHIFT	T. Shift	SURROUND	Eject / Surround
AUDIO I/II	I/II Audio	LANG I/II AUDIO	Audio / Lang I/II
ASPECT SIZE	Size/Aspect	SIZE ZOOM	Zoom / Size
TEXT	Text	GOTO TEXT	Text / Goto
REVEAL	Reveal	TOP MENU D.MENU	D. Menu / Top
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
SUBPAGE	Subpage	OPT-TOOLS SETUP	Setup / OPT /
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
RECLIST INDEX	Index/Rec List	LIST SMART	Smart / List
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
MIX ⏭	>>I	PRESET+ ⏭	>>I / Preset+
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Rechange	
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random