Original		Rechange	
POWER	Power		Power
DIMMER	Dimmer	AD SUBT	Subt
CLOCK	Clock	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
INTERNET RADIO	Internet Radio	A	Red
ONLINE MUSIC	Online Music	B	Green
MUSIC SERVER	Music Server	C	Yellow
TUNER	Tuner	D	Blue
ANALOG IN	Analog In	HOME SMART	Smart
DIGITAL IN	Digital In	ECO 3D	3D
iPod	iPod	SOUND DUAL	Dual
USB	USB	DISC NAV LIST	List
CD	CD	PICTURE FORMAT	Format
CH –	I<<<CH-		I<<
	Play	PLAY MODE	Play
	Pause		Pause
CH +	>>I / CH+		>>I

Original		Rechange	
TUNE –	<<<Tune-		<<
	Stop		Stop
TUNE +	>>>Tune+		>>
ADD FAVORITE	Favorite ADD	+ CH	Ch +
FAVORITE CALL	Favorite Call	CH –	Ch -
SDB TONE	SDB Tone	FAV PRE-CH	Pre Ch
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
TOP MENU	Top Menu	TOP MENU MENU	Menu
INFO	Info	DISPLAY INFO	Info
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
SETUP	Setup	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Rechange		Original	Rechange
ENTER	Enter	OK	Ok		
1	1	1	1		
2 ABC	2	2	2		
3 DEF	3	3	3		
4 GHI	4	4	4		
5 JKL	5	5	5		
6 MNO	6	6	6		
7 PQRS	7	7	7		
8 TUV	8	8	8		
9 WXYZ	9	9	9		
0	0	0	0		
+10 a/A	+10a/A	GUIDE	Guide		
CLEAR	Clear	CLEAR EXIT	Exit		
RANDOM	Random	APP MEDIA	Media		
REPEAT	Repeat	REPEAT TEXT	Text		
PROGRAM	Program	SHIFT + PROG SLEEP	Shift + Sleep		
MODE	Mode	SEARCH TV/R	TV/R		