Original		Rechange	
POWER	Power		Power
VIDEO	Video	SHIFT + VIDEO 4	Shift + 4
VIDEO	Video	TUNE-	<< / Tune-
SCART	Scart	OPT-TOOLS SETUP	Setup / OPT /
SCART	Scart	TUNE+	>> / Tune+
PC	PC	PC FAV MARKER	Fav / Marker / PC
PC	PC	PRESET-	I<< / Preset-
TV	TV	PROGRAM TV/ RADIO	TV/Radio /
TV	TV	PRESET+	>>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Rechange	
9	9	BLUETOOTH 9	9
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
PRE PR	PRE PR	RETURN BACK	Back / Return
	Source	RDS AV INPUT	AV / Input / RDS
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
DUAL	Dual	LANG I/II AUDIO	Audio / Lang I/II
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PICTURE	Picture	FORMAT PICTURE	Picture / Format
PR LIST	PR List	LIST SMART	Smart / List
SOUND	Sound	TITLE SOUND	Sound / Title
+	Vol+	+ VOL	Vol+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	+ CH PAGE	CH+ / Page+
–	Vol-	VOL –	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
P	P-	CH PAGE –	CH- / Page-

Original		Rechange	
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
TELETEXT	Teletext	GOTO TEXT	Text / Goto
MIX	Mix	SHIFT + GOTO TEXT	Shift + Text /
SIZE	Size	SIZE ZOOM	Zoom / Size
SUBPAGE	Subpage	SURROUND	Eject / Surround
INDEX	Index	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ

Original		Rechange	
HOLD	Hold	HOLD	Stop / Hold
REVEAL	Reveal	TOP MENU D.MENU	D.Menu / Top