Original		Rechange	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO CAL	Auto Cal	LIST SMART	Smart / List
TV/AV/⏻ SYSTEM	Tv Power	SHIFT + ⏻	Shift + Power
I/⏻ STANDBY	System Standby	⏻	Power
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
TV	TV	SHIFT + TV 1	Shift + 1
SA-CD/CD	SA-CD / CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
2CH	2 CH	NETFLIX SEARCH	Red / Netflix / Search
A.F.D.	AFD	APP REPEAT	Green / APP / Repeat
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1

Original		Rechange	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
FM MODE	FM Mode	PROGRAM TV/RADIO	TV/Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUNING	D.Tuning	SURROUND ⏏	Eject / Surround
0/10	0 / 10	HDMI - SAT 0	0
MEMORY ENTER	Enter / Memory	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	OK

Original		Rechange	
	Right		Right
	Master Vol +		Vol +
	Tv Vol +		Shift + Vol +
	Down		Down
	Menu		Menu / Home
	Master Vol -		Vol -
	Tv Vol -		Shift + Vol -
	I<< / Preset -		I<< / Preset-
	Tv CH-		Shift + CH- /
	>>I / Preset +		>>I / Preset+
	Tv CH+		Shift + CH+ /
	<< / Tuning -		<< / Tune-
	>> / Tuning +		>> / Tune+

Original	Rechange

Original		Rechange	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO CAL	Auto Cal	LIST SMART	Smart / List
SYSTEM	Power AV	SHIFT +	Shift + Power
STANDBY	Power		Power
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
TV	TV	SHIFT + TV 1	Shift + 1
SA-CD/CD	SA-CD / CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
2CH	2CH	NETFLIX SEARCH	Red / Netflix / Search
A.F.D.	A. F. D.	APP REPEAT	Green / APP / Repeat
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1

Original		Rechange	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
FM MODE	FM Mode	PROGRAM TV/ RADIO	TV/ Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUNING	D. Tuning/ D. Skip	SURROUND	Eject / Surround
>10/• -/-- CLEAR	-/--/>10	-/-- GUIDE EPG	Guide / EPG / -/--
0/10	0/10	HDMI - SAT 0	0
MEMORY ENTER	Enter/Memory	PC FAV MARKER	Fav / Marker / PC
D.SKIP DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
MUTING	Muting	DIMMER MUTE	Mute / Dimmer

Original		Rechange	
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
MASTER VOL +	Vol +	VOL +	Vol +
RETURN/EXIT	Return/Exit	RETURN BACK	Back / Return
RETURN/EXIT	Return/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
	Vol -	VOL –	Vol -
PRESET –	I<</Preset-	PRESET-	I<< / Preset-
REPLAY	←/Replay	SHIFT + PRESET-	Shift + I<< / Preset-
ADVANCE	·→/Advance	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET +	>>I/Preset+	PRESET+	>>I / Preset+
TUNING –	<</Tuning-	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
TUNING +	>>/Tuning+	TUNE+	>> / Tune+

Original		Rechange	
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold

Original		Rechange	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO CAL	Auto Cal	LIST SMART	Smart / List
SYSTEM	Power AV	SHIFT +	Shift + Power
STANDBY	Power		Power
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
TV	TV	SHIFT + TV 1	Shift + 1
SA-CD/CD	SA-CD/CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
2CH	2CH	NETFLIX SEARCH	Red / Netflix / Search
A.F.D.	A. F. D.	APP REPEAT	Green / APP / Repeat
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1

Original		Rechange	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
FM MODE	FM Mode	PROGRAM TV/ RADIO	TV/ Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUNING	D. Tuning/ D. Ski	SURROUND	Eject / Surround
>10/• -/-- CLEAR	-/--/>10	-/-- GUIDE EPG	Guide / EPG / -/--
0/10	0/10	HDMI - SAT 0	0
MEMORY ENTER	Enter/Memory	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Left		Left

Original		Rechange	
	OK		OK
	Right		Right
	Vol +		Vol +
	Down		Down
	Menu		Menu / Home
	Vol -		Vol -
	I <</ Preset -		I << / Preset -
	>>I / Preset +		>>I / Preset +
	<</ Tuning-		<< / Tune-
	Play		Play / Slow
	>>/ Tuning+		>> / Tune+
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold

Original	Rechange

Original		Rechange	
TV INPUT SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO CAL	Auto Cal	LIST SMART	Smart / List
SYSTEM	Power AV	SHIFT +	Shift + Power
STANDBY	Power		Power
VIDEO 1	Video 1	SHIFT + VIDEO 4	Shift + 4
VIDEO 2	Video 2	SHIFT + TAPE 5	Shift + 5
VIDEO 3	Video 3	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
SAT	SAT	SHIFT + HDMI - SAT 0	Shift + 0
TV	TV	SHIFT + TV 1	Shift + 1
SA-CD/CD	SA-CD / CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
2CH	2CH	NETFLIX SEARCH	Red / Netflix / Search
A.F.D.	A. F. D.	APP REPEAT	Green / APP / Repeat
MOVIE	Movie	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MUSIC	Music	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1

Original		Rechange	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
FM MODE	FM Mode	PROGRAM TV/RADIO	TV/Radio /
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
D.TUNING	D.Tuning	SURROUND	Eject / Surround
0/10	0/10	HDMI - SAT 0	0
MEMORY ENTER	Enter/Memory	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Left		Left

Original		Rechange	
	OK	OK	OK
	Right		Right
	Vol +	VOL +	Vol +
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
	Vol -	VOL –	Vol -
TV CH– PRESET–	Preset -	PRESET-	I << / Preset -
TV CH+ PRESET+	Preset +	PRESET+	>>I / Preset +
TUNING –	Tuning-	TUNE-	<< / Tune-
TUNING +	Tuning+	TUNE+	>> / Tune+

Original	Rechange