Original	Rechange	Original	Rechange
Sleep	Sleep / Timer	2	2
Auto Cal	Smart / List	3	3
Tv Power	Shift + Power	4	4
System Standby	Power	5	5
Video 1	Shift + 4	6	6
Video 2	Shift + 5	FM Mode	TV/ Radio /
Video 3	Shift + 7	7	7
DVD	Shift + 2	8	8
SAT	Shift + 0	9	9
TV	Shift + 1	D. Tuning	Eject / Surround
SA-CD / CD	Shift + 3	0 / 10	0
Tuner	Shift + 6	Enter / Memory	Fav / Marker / PC
2 CH	Red / Netflix / Search	Display	Display / Media
AFD	Green / APP / Repeat	Muting	Mute / Dimmer
Movie	Yellow / YouTube / Repeat	Up	Up
Music	Blue / Prime Video / Random	Left	Left
1	1	OK	OK

Original	Rechange	Original	Rechange
Right	Right		
Master Vol +	Vol +		
Tv Vol +	SHIFT + VOL Shift + Vol +		
Down	Down		
Menu	HOME MENU Menu / Home		
Master Vol -	VOL Vol -		
Tv Vol -	SHIFT + VOL Shift + Vol -		
I << / Preset -	PRESET- I << / Preset -		
Tv CH-	SHIFT + CH PAGE Shift + CH- /		
>>I / Preset -	PRESET+ >>I / Preset +		
Tv CH+	SHIFT + CH PAGE Shift + CH+ /		
<< / Tuning -	TUNE- << / Tune-		
>> / Tuning +	TUNE+ >> / Tune+		

Original	Rechange	Original	Rechange
Sleep	Sleep / Timer	2	2
Auto Cal	Smart / List	3	3
Power AV	Shift + Power	4	4
Power	Power	5	5
Video 1	Shift + 4	6	6
Video 2	Shift + 5	FM Mode	TV/ Radio /
Video 3	Shift + 7	7	7
DVD	Shift + 2	8	8
SAT	Shift + 0	9	9
TV	Shift + 1	D. Tuning/ D. Skip	Eject / Surround
SA-CD/CD	Shift + 3	-/--/>10	Guide / EPG / -/--
Tuner	Shift + 6	0/10	0
2CH	Red / Netflix / Search	Enter/Memory	Fav / Marker / PC
A.F.D.	Green / APP / Repeat	DVD Menu	D. Menu / Top
Movie	Yellow / YouTube / Repeat	Display	Display / Media
Music	Blue / Prime Video / Random	Tools	Setup / OPT /
1	1	Muting	Mute / Dimmer

Original		Rechange	
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
MASTER VOL +	Vol +	VOL +	Vol +
RETURN/EXIT	Return/Exit	RETURN BACK	Back / Return
RETURN/EXIT	Return/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
	Vol -	VOL –	Vol -
PRESET –	I<</Preset-	PRESET-	I<< / Preset-
REPLAY	←/Replay	SHIFT + PRESET-	Shift + I<< / Preset-
ADVANCE	·→/Advance	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET +	>>I/Preset+	PRESET+	>>I / Preset+
TUNING –	<</Tuning-	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
TUNING +	>>/Tuning+	TUNE+	>> / Tune+

Original		Rechange	
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold

Original	Rechange	Original	Rechange
Sleep	Sleep / Timer	2	2
Auto Cal	Smart / List	3	3
Power AV	Shift + Power	4	4
Power	Power	5	5
Video 1	Shift + 4	6	6
Video 2	Shift + 5	FM Mode	TV/ Radio /
Video 3	Shift + 7	7	7
DVD	Shift + 2	8	8
SAT	Shift + 0	9	9
TV	Shift + 1	D. Tuning/ D. Skip	Eject / Surround
SA-CD/CD	Shift + 3	-/--/>10	Guide / EPG / -/--
Tuner	Shift + 6	0/10	0
2CH	Red / Netflix / Search	Enter/Memory	Fav / Marker / PC
A.F.D.	Green / APP / Repeat	Display	Display / Media
Movie	Yellow / YouTube / Repeat	Muting	Mute / Dimmer
Music	Blue / Prime Video / Random	Up	Up
1	1	Left	Left

Original	Rechange	Original	Rechange
OK	OK		
Right	Right		
Vol +	Vol +		
Down	Down		
Menu	Menu / Home		
Vol -	Vol -		
I <</ Preset -	I << / Preset -		
>>I / Preset +	>>I / Preset +		
<</ Tuning-	<< / Tune-		
Play	Play / Slow		
>>/ Tuning+	>> / Tune+		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original	Rechange	Original	Rechange
Sleep	Sleep / Timer	2	2
Auto Cal	Smart / List	3	3
Power AV	Shift + Power	4	4
Power	Power	5	5
Video 1	Shift + 4	6	6
Video 2	Shift + 5	FM Mode	TV/ Radio /
Video 3	Shift + 7	7	7
DVD	Shift + 2	8	8
SAT	Shift + 0	9	9
TV	Shift + 1	D. Tuning	Eject / Surround
SA-CD / CD	Shift + 3	0/ 10	0
Tuner	Shift + 6	Enter / Memory	Fav / Marker / PC
2CH	Red / Netflix / Search	Display	Display / Media
A. F. D.	Green / APP / Repeat	Tools	Setup / OPT /
Movie	Yellow / YouTube / Repeat	Muting	Mute / Dimmer
Music	Blue / Prime Video / Random	Up	Up
1	1	Left	Left

Original	Rechange	Original	Rechange
OK	OK		
Right	Right		
Vol +	Vol +		
Down	Down		
Menu	Menu / Home		
Vol -	Vol -		
Preset -	I << / Preset -		
Preset +	>>I / Preset +		
Tuning-	<< / Tune-		
Tuning+	>> / Tune+		