Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
	Play	PLAY MODE	Play
	[≡]	REPEAT TEXT	Text
	Pause/ [/ ≡]		Pause
	Stop/ [≡+]		Stop
	Rec/ [≡♦]	REC MODE	Rec
	<<√ [≡o]		<<
	I <<√ [≡i]		I <<
	>>I / [≡?]		>>I
	>>√ [≡x]		>>
ANT	ANT	AD SUBT	Subt
TOOLS	Tools	SETTINGS OPT	Options
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4

Original		Rechange	
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
BACK/	Back	RETURN BACK	Back
HOME/ SOURCE	Home/ Source	HOME SMART	Smart
HOME/ SOURCE	Home/ Source	TIMER AV	AV
+	Vol +	+ VOL	Vol +

Original		Rechange	
	Vol -	VOL	Vol -
APPS	APPS	APP MEDIA	Medi a
P	P+	CH +	Ch +
P	P-	CH -	Ch -
	Red	A	Red
	Gr een	B	Gr een
	Yel l ow	C	Yel l ow
	Bl ue	D	Bl ue
EPG	EPG	GUIDE	Gui de
LIST	Li st	DISC NAV LIST	Li st
FAV	FAV	FAV PRE-CH	Pr e Ch
INFO	I nf o	DISPLAY INFO	I nf o
3D	3D	ECO 3D	3D

Original	Rechange