| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| AMP POWER | Power AMP | SHIFT + | Shift + Power |
| CD | CD | A | Red |
| RECORDER | Recorder | B | Green |
| NETWORK | Network | C | Yellow |
| PHONO | Phono | D | Blue |
| AUX | AUX | HOME SMART | Smart |
| TUNER | Tuner | APP MEDIA | Media |
| 1 | Internet Radio Preset 1 | SHIFT + 1 | Shift + 1 |
| 2 | Internet Radio Preset 2 | SHIFT + 2 | Shift + 2 |
| 3 | Internet Radio Preset 3 | SHIFT + 3 | Shift + 3 |
| ►/II | Play | PLAY MODE ► | Play |
| ►/II | Pause | II | Pause |
| ⏮ | I << | << | I << |
| ⏭ | >>I | >> | >>I |
| ■ | Stop | ■ | Stop |
| << | << | << | << |

| Original | | Rechange | |
|---|---|---|---|
| ►► | >> | >> | >> |
| + PRESET | Preset + | + CH | Ch + |
| PRESET — | Preset - | CH — | Ch - |
| FAVORITE PURE DIRECT | Pure Direct/Favorite | FAV PRE-CH | Pre Ch |
| ▲ VOLUME | Vol + | + VOL | Vol + |
| VOLUME ▼ | Vol - | VOL — | Vol - |
| MUTE | Mute | MUTE | Mute |
| INFO | Info | DISPLAY INFO | Info |
| MODE | Mode | PICTURE FORMAT | Format |
| SOURCE | Source | TIMER AV | AV |
| MENU | Menu | TOP MENU MENU | Menu |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ► | Right | ► | Right |
| ◄ | Left | ◄ | Left |
| ENTER | Enter | OK | Ok |
| 1 ./ | 1 | 1 | 1 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 2 ABC | 2 | 2 | 2 | | |
| 3 DEF | 3 | 3 | 3 | | |
| 4 GHI | 4 | 4 | 4 | | |
| 5 JKL | 5 | 5 | 5 | | |
| 6 MNO | 6 | 6 | 6 | | |
| 7 PQRS | 7 | 7 | 7 | | |
| 8 TUV | 8 | 8 | 8 | | |
| 9 WXYZ | 9 | 9 | 9 | | |
| 0 | 0 | 0 | 0 | | |
| +10 | +10 | GUIDE | Guide | | |
| CLEAR | Clear | CLEAR EXIT | Exit | | |
| RANDOM | Random | SETTINGS OPT | Options | | |
| REPEAT | Repeat | REPEAT TEXT | Text | | |
| PROGRAM SEARCH | Search/Program | PROG SLEEP | Sleep | | |
| DIMMER | Dimmer | SOUND DUAL | Dual | | |
| | | | | | |
| | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| AMP POWER | Power AMP | SHIFT + | Shift + Power |
| CD | CD | A | Red |
| RECORDER | Recorder | B | Green |
| NETWORK | Network | C | Yellow |
| PHONO | Phono | D | Blue |
| AUX | AUX | HOME SMART | Smart |
| TUNER | Tuner | APP MEDIA | Media |
| ►/II | Play | PLAY MODE ► | Play |
| ►/II | Pause | II | Pause |
| ⏮ | I << | K< | I << |
| ⏭ | >>I | >>I | >>I |
| ■ | Stop | ■ | Stop |
| ◄◄ | << | << | << |
| ►► | >> | >> | >> |
| + PRESET | Preset + | + CH | Ch + |
| PRESET − | Preset - | CH − | Ch - |

| Original | | Rechange | |
|---|---|---|---|
| FAVORITE PURE DIRECT | Pure Direct/Favorite | FAV PRE-CH | Pre Ch |
| ▲ VOLUME | Vol + | + VOL | Vol + |
| VOLUME ▼ | Vol - | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| INFO | Info | DISPLAY INFO | Info |
| MODE | Mode | PICTURE FORMAT | Format |
| SOURCE | Source | TIMER AV | AV |
| MENU | Menu | TOP MENU MENU | Menu |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ► | Right | ► | Right |
| ◄ | Left | ◄ | Left |
| ENTER | Enter | OK | Ok |
| 1 ./ | 1 | 1 | 1 |
| 2 ABC | 2 | 2 | 2 |
| 3 DEF | 3 | 3 | 3 |
| 4 GHI | 4 | 4 | 4 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 5 JKL | 5 | 5 | 5 | | |
| 6 MNO | 6 | 6 | 6 | | |
| 7 PQRS | 7 | 7 | 7 | | |
| 8 TUV | 8 | 8 | 8 | | |
| 9 WXYZ | 9 | 9 | 9 | | |
| 0 | 0 | 0 | 0 | | |
| +10 | +10 | GUIDE | Guide | | |
| CLEAR | Clear | EXIT | Exit | | |
| RANDOM | Random | OPT | Options | | |
| REPEAT | Repeat | TEXT | Text | | |
| PROGRAM SEARCH | Search/Program | SLEEP | Sleep | | |
| DIMMER | Dimmer | DUAL | Dual | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |