Mandis shop

RC-1032

Original		Rechange	
OPEN / CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	GUIDE	Guide
CLEAR	Clear	CLEAR EXIT	Exit
DIRECT	Direct	HOME SMART	Smart
PROGRAM	Program	PROG SLEEP	Sleep
CALL	Call	RETURN BACK	Back
RANDOM	Random	APP MEDIA	Media

Original		Rechange	
REPEAT	Repeat	REPEAT TEXT	Text
A - B	A-B	ECO 3D	3D
FOLDER MODE	Folder Mode	SEARCH TV/R	TV/R
FOLDER +	Folder+	+ CH	Ch +
FOLDER −	Folder-	CH −	Ch -
DISPLAY	Display	DISPLAY INFO	Info
II	Pause	II	Pause
TIME	Time	TIMER AV	AV
I<<	I<<	I<<	I<<
▶	Play	PLAY MODE ▶	Play
>>I	>>I	>>I	>>I
<<	<<	<<	<<
■	Stop	■	Stop
>>	>>	>>	>>

https://tout-telecommandes.fr/fr/Denon/1061604-18245-telecommande-de-remplacement-pour-Denon-RC-1032-00D3991054007.html