Mandis shop

ENE001

Original		Rechange	
Power	Power	Power	Power
Mute	Mute	MUTE	Mute
Movie	Movie	1	1
Music	Music	2	2
Photo	Photo	3	3
Home	Home	HOME SMART	Smart
Disk	Disk	TOP MENU MENU	Menu
All Media	All Media	APP MEDIA	Media
Subtitle	Subtitle	AD SUBT	Subt
Audio	Audio	SOUND DUAL	Dual
Zoom	Zoom	ZOOM	Eject
Info	Info	DISPLAY INFO	Info
Copy Target	Copy/Target	FAV PRE-CH	Pre Ch
Vol +	V+	+ VOL	Vol +
Vol -	V−	VOL −	Vol -
P+	P+	+ CH	Ch +
P-	P−	CH −	Ch -

Original		Rechange	
OK	OK	OK	Ok
Up	Up	Up	Up
Down	Down	Down	Down
Right	Right	Right	Right
Left	Left	Left	Left
Stop	Stop	Stop	Stop
Pause	Pause	Pause	Pause
<<	<<	<<	<<
>>	>>	>>	>>
I <<	Repeat	I <<	I <<
>>I	TVout	>>I	>>I
Repeat	Setup	REPEAT TEXT	Text
Tv Out	A-B	SEARCH TV/R	TV/R
Setup	BGM/Go to	SETTINGS OPT	Options
A-B	Slide Type	E-MANUAL D.MENU	D. Menu
BGM/Go to		PICTURE FORMAT	Format
Slide Type		-/-- GUIDE	Guide

https://tout-telecommande.fr/fr/Energy-Sistem/1068833-telecommande-de-remplacement-pour-Energy-Sistem-ENE001.html