Original		Rechange	
	Power		Power
MUTE	Mute	MUTE	Mute
CD 123	CD 123	C	Yellow
TUNER	Tuner	B	Green
TAPE 1/2	Tape 1/2	D	Blue
AUX/CDR	AUX/CDR	A	Red
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLOCK	Clock	TIMER AV	AV

Original		Rechange	
AUTO REV.	Auto Rev	FAV PRE-CH	Pre Ch
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	>I	>>I	>>I
	I<	I<<	I<<
	>>	>>	>>
	<<	<<	<<
DIM	Dim	SETTINGS OPT	Options
PROGRAM	Program	SHIFT + PROG SLEEP	Shift + Sleep
PERSONAL	Personal	SEARCH TV/R	TV/R
DSC	DSC	APP MEDIA	Media
VEC	VEC	HOME SMART	Smart
BASS/TREBLE	Bass/Treble	SOUND DUAL	Dual
TREBLE +	Treble+		Up
TREBLE −	Treble-		Down
BASS +	Bass+	CH +	Ch +
BASS −	Bass-	CH −	Ch -

Original		Rechange		Original		Rechange	
TIMER ON/OFF	Timer On/Off	CLEAR EXIT	Exit				
SLEEP	Sleep	PROG SLEEP	Sleep				
WOOX	Woox	ECO 3D	3D				
WOOX LEVEL	Woox Level	PICTURE FORMAT	Format				

Original		Rechange	
	Power		Power
MUTE	Mute	MUTE	Mute
CD 123	CD 123	C	Yellow
TUNER	Tuner	B	Green
TAPE 1/2	Tape 1/2	D	Blue
AUX/CDR	AUX/CDR	A	Red
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLOCK	Clock	TIMER AV	AV

Original		Rechange	
AUTO REV.	Auto Rev	FAV PRE-CH	Pre Ch
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Play	PLAY MODE ▶	Play
	Pause		Pause
	>I		>>I
	I<		I<<
	>>		>>
	<<		<<
	Stop		Stop
1 2 CD DIRECT	CD Direct 1	SHIFT + 1	Shift + 1
2 CD DIRECT	CD Direct 2	SHIFT + 2	Shift + 2
2 CD DIRECT 3	CD Direct 3	SHIFT + 3	Shift + 3
DIM	Dim	SETTINGS OPT	Options
PROGRAM	Program	SHIFT + PROG SLEEP	Shift + Sleep
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	AD SUBT	Subt

Original	Rechange	Original	Rechange
PERSONAL Personal	SEARCH TV/R TV/R		
DSC DSC	APP MEDIA Media		
VEC VEC	HOME SMART Smart		
BASS/TREBLE Bass/Treble	SOUND DUAL Dual		
TREBLE + Treble+	Up		
TREBLE - Treble-	Down		
BASS + Bass+	+ CH Ch +		
BASS - Bass-	CH - Ch -		
TIMER ON/OFF Timer On/Off	CLEAR EXIT Exit		
SLEEP Sleep	PROG SLEEP Sleep		
WOOX Woox	ECO 3D 3D		
WOOX LEVEL Woox Level	PICTURE FORMAT Format		

Original		Rechange	
	Power		Power
MUTE	Mute	MUTE	Mute
CD 123	CD 123	C	Yellow
TUNER	Tuner	B	Green
TAPE 1/2	Tape 1/2	D	Blue
AUX/CDR	AUX/CDR	A	Red
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLOCK	Clock	TIMER AV	AV

Original		Rechange	
AUTO REV.	Auto Rev	FAV PRE-CH	Pre Ch
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Play	PLAY MODE	Play
	Pause		Pause
	>I		>>I
	I<		I<<
	>>		>>
	<<		<<
	Stop		Stop
DIM	Dim	SETTINGS OPT	Options
PERSONAL	Personal	SEARCH TV/R	TV/R
DSC	DSC	APP MEDIA	Media
VEC	VEC	HOME SMART	Smart
BASS/TREBLE	Bass/Treble	SOUND DUAL	Dual
TREBLE +	Treble+		Up
TREBLE −	Treble-		Down

Original	Rechange	Original	Rechange
Bass+	Ch +		
Bass-	Ch -		
Timer On/Off	Exit		
Sleep	Sleep		
Woox	3D		
Woox Level	Format		

Original		Rechange	
	Power		Power
MUTE	Mute	MUTE	Mute
CD 123	CD 123	C	Yellow
TUNER	Tuner	B	Green
TAPE 1/2	Tape 1/2	D	Blue
AUX/CDR	AUX/CDR	A	Red
CLOCK	Clock	TIMER AV	AV
AUTO REV.	Auto Rev	FAV PRE-CH	Pre Ch
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
DIM	Dim	SETTINGS OPT	Options
PERSONAL	Personal	SEARCH TV/R	TV/R
DSC	DSC	APP MEDIA	Media
VEC	VEC	HOME SMART	Smart
BASS/TREBLE	Bass/Treble	SOUND DUAL	Dual
TREBLE	Treble+		Up
TREBLE	Treble-		Down

Original		Rechange	
BASS	Bass+	CH +	Ch +
BASS	Bass-	CH −	Ch -
TIMER ON/OFF	Timer On/Off	CLEAR EXIT	Exit
SLEEP	Sleep	PROG SLEEP	Sleep
WOOX LEVEL	Woox Level	PICTURE FORMAT	Format
WOOX	Woox	ECO 3D	3D