Original		Rechange	
OPEN / CLOSE	Open/Close	SURROUND	Eject / Surround
VIDEO ON/OFF	Video On/Off	LIST SMART	Smart / List
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer
POWER	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
RETURN	Return	RETURN BACK	Back / Return

Original		Rechange	
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
STOP	Stop	HOLD	Stop / Hold
	Down		Down
PLAY	Play	SLOW	Play / Slow
PREV	I<<	PRESET-	I<< / Preset-
NEXT	>>I	PRESET+	>>I / Preset+
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
	Pause	STEP - FREEZE	Pause / Step / Freeze
	<<	TUNE-	<< / Tune-

Original	Rechange	Original	Rechange
>>	>> / Tune+		
F.Memo	Sleep / Timer		
Video ADJ.	Picture / Format		
A-B	Yellow / YouTube / Repeat		
Repeat	Green / APP / Repeat		
Display	Display / Media		
Angle	Info / Angle		
Subtitle	Subtitle / EQ		
Audio	Audio / Lang I/II		
Last Memo	Text / Goto		
Condition Memo	AV / Input / RDS		