Original		Rechange	
	Power		Power
	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
	Sleep	TIMER SLEEP	Sleep / Timer
	Speakers A	-/-- GUIDE EPG	Guide / EPG / -/--
	Speakers B	PC FAV MARKER	Fav / Marker / PC
	Optical	AUX - HDD 7	7
	Coaxial	USB 8	8
	CD	CD - STB 3	3
	Line 1	TV 1	1
	Line 2	DVD 2	2
	Line 3	VIDEO 4	4
	Tuner	TUNER 6	6
	Net	TAPE 5	5
	Bluetooth	BLUETOOTH 9	9
	Band	PROGRAM TV/ RADIO	TV/Radio /
	<< Tuning	SHIFT + TUNE-	Shift + << /
	<< Tuning	CH PAGE -	CH- / Page-

Original		Rechange	
	Tuning >>	+ CH PAGE	CH+ / Page+
	Tuning >>	SHIFT + TUNE+	Shift + >> /
	Memory	LIST SMART	Smart / List
	< Preset	PRESET-	I<< / Preset-
	Preset >	PRESET+	>>I / Preset+
	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Mode	TITLE SOUND	Sound / Title
	Display	MEDIA DISPLAY	Display / Media
	Up		Up
	Left		Left
	Enter	OK	OK
	Right		Right
	Down		Down
	Home	HOME MENU	Menu / Home
	Return	RETURN BACK	Back / Return
	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Vol+	+ VOL	Vol+

Original	Rechange	Original	Rechange
OPTION Option	TOP MENU D.MENU D.Menu / Top		
NOW PLAYING Now Playing	ANGLE INFO Info / Angle		
VOLUME Vol-	VOL – Vol-		
MUTE Mute	DIMMER MUTE Mute / Dimmer		
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
▷/00 Play	SLOW ▶ Play / Slow		
▷/00 Pause	STEP - FREEZE ⏸ Pause / Step / Freeze		
SHUFFLE Shuffle	Prime Video RANDOM Blue / Prime Video / Random		
⏮/◁◁ I<<</<<	TUNE- ◀◀ << / Tune-		
□ Stop	HOLD ■ Stop / Hold		
▷▷/▷▷I >>/>>I	TUNE+ ▶▶ >> / Tune+		