Original		Rechange	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	[ ]	FORMAT PICTURE	Picture / Format
	Power		Power
SV	PIP	SIZE ZOOM	Zoom / Size
V= LP	V=	TOP MENU D.MENU	D.Menu / Top
000	[≡I]	-/-- GUIDE EPG	Guide / EPG / -/--
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0

Original		Rechange	
T	Pause/T	STEP - FREEZE	Pause / Step / Freeze
M	M	HOME MENU	Menu / Home
E	E	CLEAR EXIT CANCEL	Exit / Cancel / Clear
i	Info	ANGLE INFO	Info / Angle
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original		Rechange	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	[ ]	FORMAT PICTURE	Picture / Format
	Power		Power
SV	SV/[*]	SIZE ZOOM	Zoom / Size
V= LP	LP/V=	OPT-TOOLS SETUP	Setup / OPT /
000	000/[≡I]	-/-- GUIDE EPG	Guide / EPG / -/--
	Timer/Mute	TIMER SLEEP	Sleep / Timer
	Timer/Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Rechange	
0	0	HDMI - SAT 0	0
T	Pause/T	STEP - FREEZE	Pause / Step / Freeze
M	M	HOME MENU	Menu / Home
E	E	CLEAR EXIT CANCEL	Exit / Cancel / Clear
i	Rec/i	ANGLE INFO	Info / Angle
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow

Original		Rechange	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	[ ]	FORMAT PICTURE	Picture / Format
	Power		Power
SV	SV	MEDIA DISPLAY	Display / Media
V= LP	LP	LIST SMART	Smart / List
	Timer	PROGRAM TV/ RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	000	HDMI - SAT 0	0
M	M	HOME MENU	Menu / Home

Original		Rechange	
E	E	CLEAR EXIT CANCEL	Exit / Cancel / Clear
i	Rec	REC MODE	Rec / Rec Mode
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow