Original		Rechange	
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Power		Power
A SPEAKERS	Speakers A	TITLE SOUND	Sound / Title
B SPEAKERS	Speakers B	LANG I/II AUDIO	Audio / Lang I/II
OPTICAL	Optical	TV 1	1
COAXIAL	Coaxial	DVD 2	2
CD	CD	CD - STB 3	3
LINE 1	Line 1	VIDEO 4	4
LINE 2	Line 2	TAPE 5	5
PHONO	Phono	AUX - HDD 7	7
TUNER	Tuner	TUNER 6	6
NET	Net	USB 8	8
BLUETOOTH	Bluetooth	BLUETOOTH 9	9
BAND	Band	LIST SMART	Smart / List
TUNING <<	<< Tuning	SHIFT + TUNE-	Shift + << /
TUNING >>	Tuning >>	SHIFT + TUNE+	Shift + >> / Tune+

Original		Rechange	
MEMORY	Memory	REC MODE	Rec / Rec Mode
PRESET <	< Preset	CH PAGE –	CH- / Page-
PRESET <	< Preset	SHIFT + PRESET-	Shift + I<< / Preset-
PRESET >	Preset >	+ CH PAGE	CH+ / Page+
PRESET >	Preset >	SHIFT + PRESET+	Shift + >>I / Preset+
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MODE	Mode	FORMAT PICTURE	Picture / Format
DISPLAY	Display	MEDIA DISPLAY	Display / Media
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
HOME	Home	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
+ VOLUME	Volume+	+ VOL	Vol+

Original		Rechange		Original	Rechange
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools		
NOW PLAYING	Now Playing	-/-- GUIDE EPG	Guide / EPG / -/--		
VOLUME	Volume-	VOL –	Vol-		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
▷/DD	Play	SLOW ▶	Play / Slow		
▷/DD	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze		
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random		
⏮/◁◁	I<<</<<	TUNE- ◀◀	<< / Tune-		
⏮/◁◁	I<<</<<	PRESET- ⏮	I<< / Preset-		
▭	Stop	HOLD ■	Stop / Hold		
▷▷/⏭	>>/>>I	TUNE+ ▶▶	>> / Tune+		
▷▷/⏭	>>/>>I	PRESET+ ⏭	>>I / Preset+		