Original		Rechange	
TV/R	TV/R	PROGRAM TV/RADIO	TV/Radio /
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
FORMAT	Format	FORMAT PICTURE	Picture / Format
TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
F1	F1	SHIFT + TV 1	Shift + 1
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
RECALL	Recall	RETURN BACK	Back / Return
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SAT	SAT	LIST SMART	Smart / List
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Rechange	
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
AUDIO	Red / Audio	NETFLIX SEARCH	Red / Netflix / Search
AUDIO	Red / Audio	LANG I/II AUDIO	Audio / Lang I/II
PAUSE	Green / Pause	APP REPEAT	Green / APP / Repeat
PAUSE	Green / Pause	SHIFT + STEP - FREEZE II	Shift + Pause / Step /
ZOOM	Yellow / Zoom	YouTube REPEAT A-B	Yellow / YouTube / Repeat
ZOOM	Yellow / Zoom	SIZE ZOOM	Zoom / Size
INFO	Blue / Info	Prime Video RANDOM	Blue / Prime Video / Random
INFO	Blue / Info	ANGLE INFO	Info / Angle
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH+	Up / CH+		Up
VOL-	Left / Vol-		Left
OK	OK	OK	OK
VOL+	Right / Vol+		Right
CH-	Down / CH-		Down

Original		Rechange	
SUB	Sub	EQ SUBTITLE	Subtitle / EQ
TXT	Txt	GOTO TEXT	Text / Goto
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
VOL +	Vol+	+ VOL	Vol+
FIND	Find	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	Grid	MEDIA DISPLAY	Display / Media
PAGE ▲	Page+	+ CH PAGE	CH+ / Page+
VOL −	Vol-	VOL −	Vol-
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
USB	USB	SHIFT + USB 8	Shift + 8
PAGE ▼	Page-	CH PAGE −	CH- / Page-
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
▶	Play	SLOW ▶	Play / Slow
■	Stop	HOLD ■	Stop / Hold
⏮	I<<	PRESET- ⏮	I<< / Preset-

Original		Rechange	
⏭	>>I	PRESET+ ⏭	>>I / Preset+
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
●	Rec	REC MODE ●	Rec / Rec Mode

Original	Rechange		Original	Rechange	
PWR On/Off	POWER	Power	Menu	HOME MENU	Menu / Home
Mute	DIMMER MUTE	Mute / Dimmer	Menu Up		Up
H/V Play	SLOW	Play / Slow	Info	ANGLE INFO	Info / Angle
Dec/Pause	STEP-FREEZE	Pause / Step / Freeze	Menu Left		Left
East	REC MODE	Rec / Rec Mode	OK Enter	OK	OK
Lang./Rewind	TUNE-	<< / Tune-	Menu Right		Right
LNB F.Forward	TUNE+	>> / Tune+	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Dev	PRESET+	>>I / Preset+	Menu Down		Down
Audio	LANG I/II AUDIO	Audio / Lang I/II	Back	RETURN BACK	Back / Return
Subt.List	EQ SUBTITLE	Subtitle / EQ	Volume+	VOL +	Vol+
Zoom	SIZE ZOOM	Zoom / Size	SAT Sky	LIST SMART	Smart / List
Sleep Timer	TIMER SLEEP	Sleep / Timer	CH/Page+	CH PAGE +	CH+ / Page+
TV	PROGRAM TV/RADIO	TV/Radio /	Volume-	VOL −	Vol-
Sys/Serv	TOP MENU D.MENU	D.Menu / Top	Display	MEDIA DISPLAY	Display / Media
Opt?	OPT-TOOLS SETUP	Setup / OPT /	CH/Page-	CH PAGE −	CH- / Page-
Text	GOTO TEXT	Text / Goto	1. ?	TV 1	1
TV/SAT	RDS AV INPUT	AV / Input / RDS	2abc	DVD 2	2

Original	Rechange
3def	3
4ghi	4
5jkl	5
6mno	6
7pqrm	7
8tuv	8
9wxyz	9
Guide Pilote	Guide / EPG / -/--
0/10	0
FAV Pref.	Fav / Marker / PC
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Freeze	Shift + Pause / Step /
Lang./Rewind	Shift + Audio / Lang I/II
	Shift + Left

Original	Rechange
	Shift + Right
Video	Shift + 4
Epg	Shift + Guide / EPG / -/--
App	Shift + Green / APP /