Original	Rechange
Standby AV	Power
Info	Info / Angle
Direct Navigator	Smart / List
Menu	Menu / Home
EPG	Guide / EPG / -/--
Exit	Exit / Cancel / Clear
Edit	Fav / Marker / PC
<<	<< / Tune-
>>	>> / Tune+
Delete	Back / Return
Prog/Check	Setup / OPT /
Up	Up
Down	Down
Left	Left
Right	Right
OK	OK
Red	Red / Netflix / Search

Original	Rechange
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Live	Display / Media

Original	Rechange	Original	Rechange
TV/RADIO Tv/Radio	PROGRAM TV/RADIO TV/Radio /		
REC Rec	REC MODE Rec / Rec Mode		
REC PAUSE Rec Pause	SHIFT + STEP-FREEZE Shift + Pause / Step /		
VIEWER Viewer	SIZE ZOOM Zoom / Size		
SKIP Skip	RDS AV INPUT AV / Input / RDS		
BOOK SET Set Book Mark	EQ SUBTITLE Subtitle / EQ		
MARK GO Go Book Mark	SHIFT + PROGRAM TV/RADIO Shift + TV/Radio / Program		
VOLUME Vol+	+ VOL Vol+		
Vol-	VOL − Vol-		
TIMER REC Timer Rec	TIMER SLEEP Sleep / Timer		
REPLAY Replay	PRESET+ >>I / Preset+		
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
ASPECT Aspect	FORMAT PICTURE Picture / Format		

Original	Rechange
Power Tv	SHIFT + Power: Shift + Power
Tv/AV Tv	SHIFT + RDS AV INPUT: Shift + AV / Input / RDS
CH+ TV	CH+ / Page+
CH- Tv	CH- / Page-
Vol+ Tv	SHIFT + VOL +: Shift + Vol+
Vol- Tv	SHIFT + VOL −: Shift + Vol-
Standby AV	Power
Info	Info / Angle
Direct Navigator	Smart / List
Menu	Menu / Home
EPG	Guide / EPG / -/--
Exit	Exit / Cancel / Clear
Edit	Fav / Marker / PC
<<	<< / Tune-
>>	>> / Tune+
Delete	Back / Return
Prog/Check	Setup / OPT / Tools

Original	Rechange
Up	Up
Down	Down
Left	Left
Right	Right
OK	OK
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
1	1
2	2
3	3
4	4
5	5

Original		Rechange	
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
LIVE	Live	MEDIA DISPLAY	Display / Media
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
REC	Rec	REC MODE	Rec / Rec Mode
REC PAUSE	Rec Pause	SHIFT + STEP - FREEZE II	Shift + Pause / Step /
VIEWER	Viewer	SIZE ZOOM	Zoom / Size
SKIP	Skip	RDS AV INPUT	AV / Input / RDS
BOOK SET	Set Book Mark	EQ SUBTITLE	Subtitle / EQ
MARK GO	Go Book Mark	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
VOLUME	Vol+	+ VOL	Vol+
	Vol-	VOL −	Vol-
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
REPLAY	Replay	PRESET- ⏮	I<< / Preset-

Original		Rechange	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ASPECT	Aspect	FORMAT PICTURE	Picture / Format