Original		Rechange	
	Power		Power
CD	CD	CD - STB 3	3
TAPE 1/2	Tape 1/2	TAPE 5	5
TUNER	Tuner	TUNER 6	6
AUX	AUX	AUX - HDD 7	7
DBB	DBB	-/-- GUIDE EPG	Guide / EPG / -/--
DSC	DSC	PC FAV MARKER	Fav / Marker / PC
+	Volume+	+ VOL	Vol+
−	Volume-	VOL −	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
▶I	>I	PRESET+ ▶▶I	>>I / Preset+
I◀	I<	PRESET- I◀◀	I<< / Preset-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
◀◀	<<	TUNE- ◀◀	<< / Tune-
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /

Original	Rechange

Original		Rechange	
	Power		Power
CD	CD	CD - STB 3	3
TAPE 1/2	Tape 1/2	TAPE 5	5
TUNER	Tuner	TUNER 6	6
AUX	AUX	AUX - HDD 7	7
1	CD Direct 1	TV 1	1
CD DIRECT 2	CD Direct 2	DVD 2	2
3	CD Direct 3	VIDEO 4	4
DBB	DBB	-/-- GUIDE EPG	Guide / EPG / -/--
DSC	DSC	PC FAV MARKER	Fav / Marker / PC
+	Volume+	+ VOL	Vol+
−	Volume-	VOL −	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	>I	PRESET+	>>I / Preset+
	I<	PRESET-	I<< / Preset-

Original		Rechange	
	Stop	HOLD	Stop / Hold
	>>	TUNE+	>> / Tune+
	<<	TUNE-	<< / Tune-
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /

Original		Rechange		Original	Rechange
	Power		Power		
CD	CD	CD - STB 3	3		
TAPE 1/2	Tape 1/2	TAPE 5	5		
TUNER	Tuner	TUNER 6	6		
AUX	AUX	AUX - HDD 7	7		
DBB	DBB	-/-- GUIDE EPG	Guide / EPG / -/--		
DSC	DSC	PC FAV MARKER	Fav / Marker / PC		
	Volume+	+ VOL	Vol+		
	Volume-	VOL −	Vol-		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze		
	Play	SLOW	Play / Slow		
	>I	PRESET+	>>I / Preset+		
	I<	PRESET-	I<< / Preset-		
	Stop	HOLD	Stop / Hold		
	>>	TUNE+	>> / Tune+		
	<<	TUNE-	<< / Tune-		

Original		Rechange		Original	Rechange
	Power		Power		
CD	CD	CD - STB 3	3		
TAPE 1/2	Tape 1/2	TAPE 5	5		
TUNER	Tuner	TUNER 6	6		
AUX	AUX	AUX - HDD 7	7		
DBB	DBB	-/-- GUIDE EPG	Guide / EPG / -/--		
DSC	DSC	PC FAV MARKER	Fav / Marker / PC		
+	Volume+	+ VOL	Vol+		
−	Volume-	VOL −	Vol-		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		