Original		Rechange	
SHOW VIEW	Show View	ANGLE INFO	Info / Angle
	Up		Up
	Down		Down
CHECK	Check	PC FAV MARKER	Fav / Marker / PC
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
PDC/VPS	PDC/VPS	FORMAT PICTURE	Picture / Format
SP/LP	SP/LP	OPT-TOOLS SETUP	Setup / OPT /
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
STORE	Store	RETURN BACK	Back / Return
	<<	TUNE-	<< / Tune-
	Left		Left
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Right		Right
	Stop	HOLD	Stop / Hold

Original		Rechange	
VCR	Power VCR		Power
PAUSE/SLOW	Pause/Slow	STEP-FREEZE	Pause / Step / Freeze
REC/OTR	Rec/OTR	REC MODE	Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TRANSMIT	Transmit	LIST SMART	Smart / List
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TRACKING/V-LOCK	Tracking/V-Lock	CH PAGE	CH+ / Page+
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
SAT 0	0/SAT	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Rechange	Original	Rechange
Tracking/V-Lock Down	CH- / Page-		
Power TV	SHIFT + Power		
OSD	Display / Media		
Direct Tv Rec	TV/Radio /		
Tv Vol +	Vol +		
AV	SHIFT + RDS AV INPUT Shift + AV / Input / RDS		
I<< Index	I<< / Preset-		
Index >>I	>>I / Preset+		
Tv Vol -	Vol -		

Original		Rechange	
TV	Power TV		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SAT 0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
AV	AV	RDS AV INPUT	AV / Input / RDS
DIRECT TV REC	Direct Tv Rec	REC MODE	Rec / Rec Mode
OSD	OSD	MEDIA DISPLAY	Display / Media

Original		Rechange	
INDEX	I<< Index	PRESET-	I<< / Preset-
DEX	Index >>I	PRESET+	>>I / Preset+
	Up	+ CH PAGE	CH+ / Page+
	Down	CH PAGE −	CH- / Page-