| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | i / OSD | Display / Media |
| 1 | 1 | Z/ Disc Menu | Menu / Home |
| 2 | 2 | Up | Up |
| 3 | 3 | P+ | CH+ / Page+ |
| PIP | Info / Angle | Left | Left |
| 4 | 4 | Vol - | Vol - |
| 5 | 5 | OK | OK |
| 6 | 6 | Right | Right |
| [ <>] | Picture / Format | Vol + | Vol + |
| >I | >>I / Preset+ | TXT | Text / Goto |
| 7 | 7 | << | << / Tune- |
| 8 | 8 | Down | Down |
| 9 | 9 | P- | CH- / Page- |
| ? | Smart / List | TV-G | Guide / EPG / -/-- |
| I < | I << / Preset- | >> | >> / Tune+ |
| 0 | 0 | Red/ Image/ I > | Red / Netflix / Search |
| Mute | Mute / Dimmer | Green/ Timer | Green / APP / Repeat |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Play | Play / Slow | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Pause | Pause / Step / Freeze | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Disc Menu | D. Menu / Top |
| 1 | 1 | Disc Menu | Menu / Home |
| 2 | 2 | Up | Up |
| 3 | 3 | P+ | CH+ / Page+ |
| Audio | Audio / Lang I/II | Left | Left |
| 4 | 4 | Vol - | Vol - |
| 5 | 5 | OK | OK |
| 6 | 6 | Right | Right |
| [ <>] | Zoom / Size | Vol + | Vol + |
| >I | >>I / Preset+ | TXT | Text / Goto |
| 7 | 7 | << | << / Tune- |
| 8 | 8 | Down | Down |
| 9 | 9 | P- | CH- / Page- |
| ? | Smart / List | TV-G | Guide / EPG / -/-- |
| I < | I << / Preset- | >> | >> / Tune+ |
| 0 | 0 | Red/Picture | Picture / Format |
| i / OSD | Display / Media | Red/Picture | Red / Netflix / Search |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Green / Timer | Sleep / Timer | | |
| Play | Play / Slow | | |
| Green / Timer | Green / APP / Repeat | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Pause | Pause / Step / Freeze | | |
| Blue/Sound | Sound / Title | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | i / OSD | Display / Media |
| 1 | 1 | Z/ Disc Menu | Menu / Home |
| 2 | 2 | Up | Up |
| 3 | 3 | P+ | CH+ / Page+ |
| Audio | Audio / Lang I/II | Left | Left |
| 4 | 4 | Vol - | Vol - |
| 5 | 5 | OK | OK |
| 6 | 6 | Right | Right |
| [ <>] | Zoom / Size | Vol + | Vol + |
| >I | >>I / Preset+ | TXT | Text / Goto |
| 7 | 7 | << | << / Tune- |
| 8 | 8 | Down | Down |
| 9 | 9 | P- | CH- / Page- |
| ? | Smart / List | TV-G | Guide / EPG / -/-- |
| I < | I << / Preset- | >> | >> / Tune+ |
| 0 | 0 | Red/ Image/ I > | Red / Netflix / Search |
| Mute | Mute / Dimmer | Red/ Image/ I > | Shift + Play / Slow |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Green/Timer | Green / APP / Repeat | | |
| Play | Play / Slow | | |
| Green/Timer | Sleep / Timer | | |
| Pause | Pause / Step / Freeze | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Z/ Disc Menu | Menu / Home |
| 1 | 1 | P+ | CH+ / Page+ |
| 2 | 2 | Up | Up |
| 3 | 3 | Left | Left |
| PIP/ Audio | Audio / Lang I/II | Vol - | Vol - |
| 4 | 4 | OK | OK |
| 5 | 5 | Right | Right |
| 6 | 6 | Vol + | Vol + |
| [ <>] | Zoom / Size | TXT | Text / Goto |
| >I | >>I / Preset+ | << | << / Tune- |
| 7 | 7 | P- | CH- / Page- |
| 8 | 8 | Down | Down |
| 9 | 9 | TV-G | Guide / EPG / -/-- |
| ? | Smart / List | >> | >> / Tune+ |
| I < | I << / Preset- | Red/ Image/ I > | Picture / Format |
| 0 | 0 | Red/ Image/ I > | Red / Netflix / Search |
| i / OSD | Display / Media | Green/ Timer | Green / APP / Repeat |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Play | Play / Slow | | |
| Green/Timer | Sleep / Timer | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Pause | Pause / Step / Freeze | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |