# Mandis shop

LG AKB74955392

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Delete | Exit / Cancel / Clear |
| Mute | Mute / Dimmer | Vol + | Vol + |
| Play | Play / Slow | F | Smart / List |
| Pause | Pause / Step / Freeze | Preset/Folder Up | CH+ / Page+ |
| Stop | Stop / Hold | Vol - | Vol - |
| USB Rec | Rec / Rec Mode | Preset/Folder | CH- / Page- |
| I<</Tuning- | I<< / Preset- | 1 | 1 |
| >>I/Tuning+ | >>I / Preset+ | 2 | 2 |
| Special EQ | Audio / Lang I/II | 3 | 3 |
| Auto DJ | Subtitle / EQ | 4 | 4 |
| Open/Close | Eject / Surround | 5 | 5 |
| Alarm | Zoom / Size | 6 | 6 |
| Sleep | Sleep / Timer | 7 | 7 |
| PTY | TV/Radio / | 8 | 8 |
| Jukebox/Memor | Setup / OPT / | 9 | 9 |
| RDS/Set | Menu / Home | Equalizer | Guide / EPG / -/-- |
| (i) | Info / Angle | 0 | 0 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| REPEAT | Repeat | APP / REPEAT | Green / APP / Repeat | | |
| CLOCK | Clock | SHIFT + TIMER / SLEEP | Shift + Sleep / Timer | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |