Mandis shop

REMCON2008

Original		Rechange		Original	Rechange
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /		
-10	-10	-/-- GUIDE EPG	Guide / EPG / -/--		
+10	+10	PC FAV MARKER	Fav / Marker / PC		
▶/II	Play	SLOW ▶	Play / Slow		
▶/II	Pause	STEP - FREEZE II	Pause / Step / Freeze		
I◀◀/◀◀	<<	TUNE- ◀◀	<< / Tune-		
I◀◀/◀◀	I<<	PRESET- I◀◀	I<< / Preset-		
▶▶/▶▶I	>>	TUNE+ ▶▶	>> / Tune+		
▶▶/▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+		
STOP	Stop	HOLD ■	Stop / Hold		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
VOL-	Vol-	VOL −	Vol-		
VOL+	Vol+	+ VOL	Vol+		

https://tout-telecommandes.fr/fr/PRO-BASIC/1066622-96443-telecommande-de-remplacement-pour-PRO-BASIC-REMCON2008.html