Mandis shop

CU-XR005

Original		Rechange	
POWER	Power		Power
VOLU	Volume-	VOL –	Vol-
LUME +	Volume+	+ VOL	Vol+
FUNC -TION	Function	HOME MENU	Menu / Home
SFC PRESET	SFC Preset	LIST SMART	Smart / List
SMART OPE.	Smart Ope.	MEDIA DISPLAY	Display / Media
SCAN	Scan	RETURN BACK	Back / Return
TU STA	Tuner Station-	CH PAGE –	CH- / Page-
NER TION +	Tuner Station+	+ CH PAGE	CH+ / Page+
	Stop Deck II	SHIFT + OK	Shift + OK
	Stop Deck	OK	OK
DECK	< Deck II	SHIFT + ◀	Shift + Left
DECK	< Deck	◀	Left
DECK ▶	Deck II >	▶	Right
DECK ▶	> Deck	SHIFT + ▶	Shift + Right
	Rec/Pause Deck II	REC MODE	Rec / Rec Mode
	<< Deck II	SHIFT + TUNE- ◀◀	Shift + << / Tune-

Original		Rechange	
	<< Deck	TUNE- ◀◀	<< / Tune-
	>> Deck II	SHIFT + TUNE+ ▶▶	Shift + >> /
	>> Deck	TUNE+ ▶▶	>> / Tune+
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
CD ▶	Play CD	SLOW ▶	Play / Slow
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	I<< CD	PRESET- ⏮	I<< / Preset-
	>>I CD	PRESET+ ⏭	>>I / Preset+
SNOOZE	Snooze	ANGLE INFO	Info / Angle
	Pause CD	STEP-FREEZE ⏸	Pause / Step / Freeze
	Stop CD	HOLD ■	Stop / Hold

https://tout-telecommandes.fr/fr/Pioneer/1066817-91362-telecommande-de-remplacement-pour-Pioneer-CU-XR005.html