Mandis shop

Epson 1556256

Original		Rechange	
	Power		Power
Source	Source	RDS AV INPUT	AV / Input / RDS
Aspect	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
Color Mode	Color Mode	FORMAT PICTURE	Picture / Format
User	User	LIST SMART	Smart / List
	Transfers control to the iPod	MEDIA DISPLAY	Display / Media
Menu	Menu	HOME MENU	Menu / Home
Esc	Esc	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
	Ok	OK	OK
	Right		Right
	Down		Down
	Play/Pause	SLOW	Play / Slow
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	Vol-	VOL	Vol-

Original		Rechange	
	Vol+	VOL	Vol+
	AV Mute/Images On/Off	DIMMER MUTE	Mute / Dimmer
	Ilumination	RETURN BACK	Back / Return

https://tout-telecommandes.fr/fr/Epson/1067190-66056-telecommande-de-remplacement-pour-Epson-1556256.html