Mandis shop

RC-217

Original		Rechange	
PLAY	Play	SLOW ▶	Play / Slow
PAUSE	Pause	STEP·FREEZE ⏸	Pause / Step / Freeze
STOP	Stop	HOLD ■	Stop / Hold
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
OPEN/CLOSE	Open/Close	SURROUND ⏏	Eject / Surround
AUTO EDIT	Auto Edit	SIZE ZOOM	Zoom / Size
TIME	Time	TIMER SLEEP	Sleep / Timer
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
AUTO SPACE	Auto Space	GOTO TEXT	Text / Goto
INDEX	Index	ANGLE INFO	Info / Angle
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOLUME+	Volume+	+ VOL	Vol +
DIRECT	Direct	LIST SMART	Smart / List
VOLUME-	Volume-	VOL −	Vol -

Original		Rechange	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD·STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX·HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
10	10	HDMI·SAT 0	0
CALL	Call	PC FAV MARKER	Fav / Marker / PC
ALL	Repeat All	NETFLIX SEARCH	Red / Netflix / Search
REPEAT(1)	Repeat (1)	APP REPEAT	Green / APP / Repeat
A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random

https://tout-telecommande.fr/fr/Denon/1620-254-telecommande-remplacement-pour-Denon-RC-217.html