Mandis shop

Panasonic N2QAYB000471

Original		Rechange	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
VOL	Vol + Tv	VOL +	Vol +
CH	CH+ Tv	SHIFT + CH PAGE +	Shift + CH+ /
DRIVE SELECT	Drive Select	LIST SMART	Smart / List
AV	AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOL	Vol - Tv	VOL −	Vol -
CH	CH- Tv	SHIFT + CH PAGE −	Shift + CH- /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
PAGE CH	Page/CH+	CH PAGE +	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	Page/CH-	CH PAGE −	CH- / Page-
7	7	AUX - HDD 7	7

Original		Rechange	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ShowView	ShowView	FORMAT PICTURE	Picture / Format
DELETE *	Delete	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
PROG/CHECK	Prog/Check	PROGRAM TV/RADIO	TV/Radio /
SKIP	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SLOW/SEARCH	<< Slow/Search	TUNE-	<< / Tune-
SLOW/SEARCH	Slow/Search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY/x1.3	Play	SLOW	Play / Slow
STATUS	i/Status	ANGLE INFO	Info / Angle
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original	Rechange
Direct Navigator	D.Menu / Top
Left	Left
OK	OK
Up	Up
Right	Right
Function Menu	Menu / Home
Down	Down
Return	Back / Return
Option	Setup / OPT /
Red/Audio	Red / Netflix / Search
Green/Chapter	Green / APP / Repeat
Yellow/Manual Skip -10s	Yellow / YouTube / Repeat
Blue/Manual Skip +60s	Blue / Prime Video / Random
Rec	Rec / Rec Mode
Rec Mode	Shift + Rec / Rec Mode
Ext Link	Zoom / Size
Direct Tv Rec	Shift + TV/Radio / Program

Original	Rechange
Text	Text / Goto
STTL	Subtitle / EQ
Display	Display / Media
Time Slip	Sleep / Timer