| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | [≡i] / Menu | Menu / Home |
| Mute | Mute / Dimmer | Up | Up |
| Play | Play / Slow | [≡?] / Info | Info / Angle |
| Pause | Pause / Step / Freeze | Left | Left |
| Stop | Stop / Hold | Enter | OK |
| << | << / Tune- | Right | Right |
| >> | >> / Tune+ | [≡x] / Exit | Exit / Cancel / Clear |
| P Down | I<< / Preset- | Down | Down |
| P Up | >>I / Preset+ | Vol + | Vol + |
| I-II / Dual | Audio / Lang I/II | P+ | CH+ / Page+ |
| (o) / SRS | Subtitle / EQ | Vol - | Vol - |
| [≡+] / PIP | Picture / Format | DNIe | Display / Media |
| [≡♦] / Swap | Zoom / Size | P- | CH- / Page- |
| Sleep | Sleep / Timer | 1 | 1 |
| TV | TV/Radio / | 2 | 2 |
| TTX/MIX | Text / Goto | 3 | 3 |
| Source | AV / Input / RDS | 4 | 4 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| -/-- | -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| PRE-CH | [≡o] / Pre-CH | PC FAV MARKER | Fav / Marker / PC | | |
| P.MODE | Red/-I[ ]I-/P.Mo | NETFLIX SEARCH | Red / Netflix / Search | | |
| S.MODE | Green/-I♪I-/S.Mo e | APP REPEAT | Green / APP / Repeat | | |
| STILL | Yellow/[▼]/Stil | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| P.SIZE | Blue/[<>]/P.Size | Prime Video RANDOM | Blue / Prime Video / Random | | |
| TIME | Time | SHIFT + TIMER SLEEP | Shift + Sleep / Timer | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | POWER | Power |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| PLAY/PAUSE | Play | SLOW | Play / Slow |
| PLAY/PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| STOP | Stop | HOLD | Stop / Hold |
| REW | << | TUNE- | << / Tune- |
| FF | >> | TUNE+ | >> / Tune+ |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / |
| MENU | [≡i] / Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| INFO | [≡?] / Info | ANGLE INFO | Info / Angle |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| EXIT | [≡x] / Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Down | | Down |
| | Vol + | VOL + | Vol + |

| Original | | Rechange | |
|---|---|---|---|
| | Vol - | VOL − | Vol - |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| PLAY/PAUSE | Play | SLOW | Play / Slow |
| PLAY/PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| STOP | Stop | HOLD | Stop / Hold |
| REW | << | TUNE- | << / Tune- |
| FF | >> | TUNE+ | >> / Tune+ |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / |
| SOURCE | Source | RDS AV INPUT | AV / Input / RDS |
| MENU | [≡i] / Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| INFO | [≡?] / Info | ANGLE INFO | Info / Angle |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| EXIT | [≡x] / Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | | Rechange | |
|---|---|---|---|
| | Down | | Down |
| | Vol + | VOL + | Vol + |
| P | P+ | CH PAGE + | CH+ / Page+ |
| | Vol - | VOL - | Vol - |
| | P- | CH PAGE - | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| PRE-CH | [≡o] / Pre-CH | PC FAV MARKER | Fav / Marker / PC |
| POWER | Power Cable | SHIFT + | Shift + Power |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| P+ Cable | SHIFT + CH PAGE + | Shift + CH+ / | |
| P- Cable | SHIFT + CH PAGE − | Shift + CH- / | |
| 1 Cable | SHIFT + TV 1 | Shift + 1 | |
| 2 Cable | SHIFT + DVD 2 | Shift + 2 | |
| 3 Cable | SHIFT + CD - STB 3 | Shift + 3 | |
| 4 Cable | SHIFT + VIDEO 4 | Shift + 4 | |
| 5 Cable | SHIFT + TAPE 5 | Shift + 5 | |
| 6 Cable | SHIFT + TUNER 6 | Shift + 6 | |
| 7 Cable | SHIFT + AUX - HDD 7 | Shift + 7 | |
| 8 Cable | SHIFT + USB 8 | Shift + 8 | |
| 9 Cable | SHIFT + BLUETOOTH 9 | Shift + 9 | |
| 0 Cable | SHIFT + HDMI - SAT 0 | Shift + 0 | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / |
| STOP | Stop | HOLD | Stop / Hold |
| PLAY/PAUSE | Play | SLOW | Play / Slow |
| PLAY/PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| FF | >> | TUNE+ | >> / Tune+ |
| REW | << | TUNE- | << / Tune- |

| Original | | Rechange | |
|---|---|---|---|
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| P | P+ | CH PAGE + | CH+ / Page+ |
| | P- | CH PAGE − | CH- / Page- |
| | Vol + | VOL + | Vol + |
| | Vol - | VOL − | Vol - |
| ENTER | Enter | OK | OK |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |