Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Tv/Radio	SEARCH TV/R	TV/R
	Recall	RETURN BACK	Back
i	i	DISPLAY INFO	Info
L/R	L/R	APP MEDIA	Media
▶/II	Play	PLAY MODE ▶	Play

Original		Rechange	
▶/II	Pause	II	Pause
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
DIGEST	Digest	SETTINGS OPT	Options
FAV	FAV	FAV PRE-CH	Pre Ch
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
SCAN	Scan	HOME SMART	Smart
EDIT	Edit	ECO 3D	3D
EPG	EPG	-/-- GUIDE	Guide
EPG	Red	A	Red
AUDIO	Green	B	Green
SUBTITLE	Yellow	C	Yellow
TTX	Blue	D	Blue

Original		Rechange	
AUDIO	Audi o	SOUND DUAL	Dual
SUBTITLE	Subt i t l e	AD SUBT	Subt
TTX	TTX	REPEAT TEXT	Text

Original	Rechange