| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| A-B | A-B | ECO 3D | 3D |
| CLEAR | Clear | CLEAR EXIT | Exit |
| | Open/Close | ZOOM | Eject |
| TIME | Time | TIMER AV | AV |
| RESUME | Resume | DISPLAY INFO | Info |
| PROG | Prog | PROG SLEEP | Sleep |
| AUDIO | Audio | SOUND DUAL | Dual |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| ZOOM | Zoom | SHIFT + ZOOM | Shift + Eject |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |

| Original | | Rechange | |
|---|---|---|---|
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0/10 | 0/10 | 0 | 0 |
| 10+ | 10+ | -/-- GUIDE | Guide |
| RAN | Ran | SEARCH TV/R | TV/R |
| OSD | OSD | PICTURE FORMAT | Format |
| RETURN | Return | RETURN BACK | Back |
| REPEAT | Repeat | REPEAT TEXT | Text |
| SLOW | Slow | B | Green |
| MENU | Menu | TOP MENU MENU | Menu |
| ANGLE | Angle | A | Red |
| VOL+ | Vol+ | + VOL | Vol + |
| VOL− | Vol- | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| SURROUND | Surround | C | Yellow |
| L/R | L/R | HOME SMART | Smart |
| SETUP | Setup | SETTINGS OPT | Options |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| | Up | | Up | | |
| | Down | | Down | | |
| | Right | | Right | | |
| | Left | | Left | | |
| ENTER | Enter | OK | Ok | | |
| STOP | Stop | | Stop | | |
| PLAY | Play | PLAY MODE | Play | | |
| | I<< | | I<< | | |
| | >>I | | >>I | | |
| N/P | N/P | APP MEDIA | Media | | |
| | << | | << | | |
| | >> | | >> | | |
| PAUSE/STEP | Pause/Step | | Pause | | |
| PBC | PBC | E-MANUAL D.MENU | D. Menu | | |
| TITLE | Title | DISC NAV LIST | List | | |
| | | | | | |
| | | | | | |