Mandis shop

Denon RC-1216

Original	Rechange	Original	Rechange
Power	Power	Mute	Mute
Sleep	Sleep	Info	Info
CBL/SAT	1	Option	Options
Blu-ray	2	Back	Back
DVD/Blu-ray	3	Setup	Menu
Game	4	Up	Up
Tv Audio	5	Down	Down
Media Player	6	Right	Right
USB	7	Left	Left
AM	8	Enter	Ok
FM	9	CH Level	TV/R
Bluetooth	0	Mode	Subt
CH/Page +	Ch +	Memory	Guide
CH/Page -	Ch -	I << / Tune -	I <<
Eco	3D	Play	Play
Volume +	Vol +	Pause	Pause
Volume -	Vol -	>>I / Tune +	>>I

Original	Rechange	Original	Rechange
Quick Select 1	Red		
Quick Select 2	Green		
Quick Select 3	Yellow		
Quick Select 4	Blue		
< Sound Mode	<<		
Sound Mode >	>>		
Audio Delay +	Smart		
Audio Delay -	Media		