| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| CBL/SAT | CBL/SAT | 1 | 1 |
| Blu-ray | Blu-ray | 2 | 2 |
| DVD/ Blu-ray | DVD/Blu-ray | 3 | 3 |
| GAME | Game | 4 | 4 |
| TV AUDIO | Tv Audio | 5 | 5 |
| MEDIA PLAYER | Media Player | 6 | 6 |
| Bluetooth | Bluetooth | 7 | 7 |
| AM | AM | 8 | 8 |
| FM | FM | 9 | 9 |
| CHANNEL | CH+ | CH + | Ch + |
| CHANNEL | CH- | CH – | Ch - |
| ECO | Eco | ECO 3D | 3D |
| VOLUME | Vol + | VOL + | Vol + |
| VOLUME | Vol - | VOL – | Vol - |
| MUTE | Mute | MUTE | Mute |

| Original | | Rechange | |
|---|---|---|---|
| INFO | Info | DISPLAY INFO | Info |
| OPTION | Option | SETTINGS OPT | Options |
| BACK | Back | RETURN BACK | Back |
| SETUP | Setup | TOP MENU MENU | Menu |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| CH LEVEL | CH Level | SOUND DUAL | Dual |
| MODE | Mode | AD SUBT | Subt |
| MEMORY | Memory | FAV PRE-CH | Pre Ch |
| TUNE – | I<</ Tune- | | I << |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| TUNE + | Tune+/ >>I | | >>I |
| 1 | Quick Select 1 | A | Red |

| Original | | Rechange | |
|---|---|---|---|
| QUICK 2 | Quick Select 2 | B | Green |
| SELECT 3 | Quick Select 3 | C | Yellow |
| 4 | Quick Select 4 | D | Blue |
| SOUND | < Sound Mode | « | << |
| D MODE | Sound Mode > | » | >> |
| D DELAY + | Audio Delay+ | HOME SMART | Smart |
| AUDIO – | Audio Delay- | APP MEDIA | Media |

| Original | Rechange |
|---|---|
| | |