Original		Rechange	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
MEDIA PLAYER	Media Player	DVD 2	2
Blu-ray	Blu-ray	CD - STB 3	3
GAME	Game	VIDEO 4	4
AUX1	AUX1	TAPE 5	5
AUX2	AUX2	AUX - HDD 7	7
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--
TV AUDIO	Tv Audio	TV 1	1
TUNER	Tuner	TUNER 6	6
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	PC FAV MARKER	Fav / Marker / PC
.:I:.	.:I:.	LIST SMART	Smart / List
CH/PAGE	CH/Page Up	+ CH PAGE	CH+ / Page+
ECO	Eco	MEDIA DISPLAY	Display / Media

Original		Rechange	
VOLUME	Volume+	+ VOL	Vol+
CH/PAGE	CH/Page Down	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol-
INFO	Info	ANGLE INFO	Info / Angle
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
TUNE-	I<<</Tune-	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
TUNE+	>>I/Tune+	PRESET+	>>I / Preset+

Original		Rechange	
1	Quick Select 1	TITLE SOUND	Sound / Title
2	Quick Select 2	LANG I/II AUDIO	Audio / Lang I/II
3	Quick Select 3	EQ SUBTITLE	Subtitle / EQ
4	Quick Select 4	SURROUND	Eject / Surround
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search
GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original	Rechange