Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Audio		Audio / Lang I/II
	0		0
	Aspect / Subtitl		Zoom / Size
	Aspect / Subtitl		Subtitle / EQ
	PIP / Recall		Fav / Marker / PC
	AV		AV / Input / RDS
	Mute		Mute / Dimmer

Original		Rechange	
	i		Info / Angle
	Up / P+		Up
	Up / P+		CH+ / Page+
	Z / Return		Back / Return
	Left / Vol -		Left
	Left / Vol -		Vol -
	OK		OK
	Right / Vol +		Right
	Right / Vol +		Vol +
	TXT / Menu		Menu / Home
	TXT / Menu		Text / Goto
	Down / P-		Down
	Down / P-		CH- / Page-
	TV-G / Top		D.Menu / Top
	Red / Rec		Rec / Rec Mode
	Red / Rec		Red / Netflix / Search
	Green / Play		Play / Slow

Original	Rechange	Original	Rechange
Green / Play	Green / APP / Repeat		
Yellow / Pause	Yellow / YouTube / Repeat		
Yellow / Pause	Pause / Step / Freeze		
Blue / Stop	Blue / Prime Video / Random		
Blue / Stop	Stop / Hold		
Scan / I<	I<< / Preset-		
PAT / >I	>>I / Preset+		
S / <<	<< / Tune-		
P / >>	>> / Tune+		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Langs		Audio / Lang I/II
	0		0
	[<>]/[...]		Subtitle / EQ
	PIP / Repeat		Shift + Green / APP /
	AV		AV / Input / RDS
	Mute		Mute / Dimmer
	i		Info / Angle

Original		Rechange	
	P+		CH+ / Page+
	Up		Up
	Vol -		Vol -
	Left		Left
	OK		OK
	Vol +		Vol +
	Right		Right
	TXT/Menu		Menu / Home
	P-		CH- / Page-
	Down		Down
	TV-G/Top Menu		D.Menu / Top
	Red/Picture/Re		Red / Netflix / Search
	Red/Picture/Re		Picture / Format
	Green/Timer/Play		Green / APP / Repeat
	Green/Timer/Play		Play / Slow
	Green/Timer/Play		Sleep / Timer
	Yellow/Pause		Yellow / YouTube / Repeat

Original		Rechange		Original	Rechange
	Yellow/ Pause	STEP-FREEZE	Pause / Step / Freeze		
	Blue/ Audio/ Stop	TITLE SOUND	Sound / Title		
	Blue/ Audio/ Stop	HOLD	Stop / Hold		
	Blue/ Audio/ Stop	Prime Video RANDOM	Blue / Prime Video / Random		
SCAN	I◁/ Scan	PRESET-	I<< / Preset-		
PAT	▷I / PAP	PRESET+	>>I / Preset+		
S	<<◁/ S	TUNE-	<< / Tune-		
P	>>▷/ P	TUNE+	>> / Tune+		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Langs		Audio / Lang I/II
	0		0
	[<>] / [. . .]		Zoom / Size
	[<>] / [. . .]		Subtitle / EQ
	PIP/ Repeat	+	Shift + Green / APP /
	AV		AV / Input / RDS
	Mute		Mute / Dimmer

Original		Rechange	
	i		Info / Angle
	P+		CH+ / Page+
	Up		Up
	Vol -		Vol -
	Left		Left
	OK		OK
	Vol +		Vol +
	Right		Right
	TXT/ Menu		Menu / Home
	P-		CH- / Page-
	Down		Down
	TV-G/ Top Menu		D. Menu / Top
	Red/ Picture/ Rec		Rec / Rec Mode
	Red/ Picture/ Rec		Picture / Format
	Red/ Picture/ Rec		Red / Netflix / Search
	Green/ Timer >/ Pla		Green / APP / Repeat
	Green/ Timer >/ Pla		Play / Slow

y

Original		Rechange		Original	Rechange
	Green/Timer >/Pla	TIMER SLEEP	Sleep / Timer		
	Yellow/Pause	STEP-FREEZE	Pause / Step / Freeze		
	Yellow/Pause	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue/Audio/Stop	TITLE SOUND	Sound / Title		
	Blue/Audio/Stop	Prime Video RANDOM	Blue / Prime Video / Random		
	Blue/Audio/Stop	HOLD	Stop / Hold		
	I</Scan	PRESET-	I<< / Preset-		
	>I/PAP	PRESET+	>>I / Preset+		
	<<</S	TUNE-	<< / Tune-		
	>>/P	TUNE+	>> / Tune+		