Original		Rechange	
	Power		Power
SOURCE	Source	TIMER AV	AV
P.MODE	P. Mode	PICTURE FORMAT	Format
S.MODE	S. Mode	SEARCH TV/R	TV/R
	Home	HOME SMART	Smart
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
Q.VIEW	Q. View	SETTINGS OPT	Options
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Rechange	
	Mute	MUTE	Mute
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL −	Vol -
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
AUDIO I/II	I/II / Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
You Tube	You Tube	APP MEDIA	Media
INFO	Info	DISPLAY INFO	Info
FAV	FAV	FAV PRE-CH	Pre Ch
SCREEN	Screen	ECO 3D	3D
CH.LIST	CH List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
	Up		Up
	Down		Down
	Right		Right

Original		Rechange	
	Left		Left
OK	OK	OK	Ok
BACK/	Back	RETURN BACK	Back
EXIT/	Exit	CLEAR EXIT	Exit
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Text	REPEAT TEXT	Text
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	Rec	REC MODE	Rec

Original	Rechange