Mandis shop

JVC RM-RXUV5R

Original		Rechange	
⏻/I	Power	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	APP MEDIA	Media
DISPLAY	Display	DISPLAY INFO	Info
FM MODE	FM Mode	SEARCH TV/R	TV/R
MD / AUX	MD/AUX	A	Red
AHB PRO	AHB PRO	HOME SMART	Smart
AUTO PRESET	Auto Preset	ECO 3D	3D
CD ⏏	Open/Close CD	ZOOM ⏏	Eject
PROGRAM	Program	SHIFT + PROG SLEEP	Shift + Sleep
RANDOM	Random	AD SUBT	Subt
REPEAT	Repeat	REPEAT TEXT	Text
BASS	Bass	B	Green
TREBLE	Treble	C	Yellow
CANCEL	Cancel	RETURN BACK	Back
UP	Up	▲	Up
DOWN	Down	▼	Down

Original		Rechange	
>	Right	▶	Right
<	Left	◀	Left
SET	Set	OK	Ok
PTY/ EON	PTY EON	TIMER AV	AV
TAPE ◁ ▷	<> Tape	❚❚	Pause
DISPLAY MODE	Display Mode	SHIFT + DISPLAY INFO	Shift + Info
TUNER BAND	Tuner/Band	SOUND DUAL	Dual
CD ▷❚❚	Play/Pause CD	PLAY MODE ▶	Play
▶▶I	>>I	≫	>>I
■	Stop	■	Stop
I◀◀	I<<	≪	I<<
+ VOLUME	Volume+	+ VOL	Vol +
VOLUME –	Volume-	VOL –	Vol -

https://tout-telecommandes.fr/fr/JVC/1064138-12586-telecommande-de-remplacement-pour-JVC-RM-RXUV5R.html