Original		Rechange	
AMP POWER	AMP Power		Power
POWER	Power	SHIFT +	Shift + Power
CD	CD	C	Yellow
TUNER	Tuner	B	Green
NETWORK	Network	APP MEDIA	Media
PHONO	Phono	HOME SMART	Smart
AUX	AUX	A	Red
RECORDER	Recorder	D	Blue
I<<	I<<		I<<
>>I	>>I		>>I
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
INPUT	Input	TIMER AV	AV
INFO	Info	DISPLAY INFO	Info
SOURCE DIRECT	Source Direct	ECO 3D	3D
VOLUME	Vol+	VOL +	Vol +

Original		Rechange	
VOLUME	Vol-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
TOP MENU TIME	Time/Top Menu	TOP MENU MENU	Menu
MODE	Mode	RETURN BACK	Back
FAVORITES PROG	Prog/Favorites	FAV PRE-CH	Pre Ch
SETUP	Setup	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6

Original		Rechange	
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
0	0	0	0
a/A +10	+10	-/-- GUIDE	Guide
CLEAR	Clear	CLEAR EXIT	Exit
DIMMER	Dimmer	PICTURE FORMAT	Format
RANDOM	Random	AD SUBT	Subt
REPEAT	Repeat	REPEAT TEXT	Text
SEARCH	Search	SEARCH TV/R	TV/R

Original	Rechange

Original		Rechange	
AMP POWER	AMP Power		Power
POWER	Power	SHIFT +	Shift + Power
CD	CD	C	Yellow
TUNER	Tuner	B	Green
NETWORK	Network	APP MEDIA	Media
PHONO	Phono	HOME SMART	Smart
AUX	AUX	A	Red
RECORDER	Recorder	D	Blue
I<<	I<<	K<	I<<
SOUND MODE	Sound Mode	SOUND DUAL	Dual
>>I	>>I	>>	>>I
■	Stop	■	Stop
▶	Play	PLAY MODE ▶	Play
II	Pause	II	Pause
INPUT	Input	TIMER AV	AV
INFO	Info	DISPLAY INFO	Info
SOURCE DIRECT	Source Direct	ECO 3D	3D

Original		Rechange	
VOLUME ▲	Vol+	+ VOL	Vol +
VOLUME ▼	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TOP MENU TIME	Time/Top Menu	TOP MENU MENU	Menu
MODE	Mode	RETURN BACK	Back
FAVORITES PROG	Prog/Favorites	FAV PRE-CH	Pre Ch
SETUP	Setup	SETTINGS OPT	Options
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok
1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5

Original		Rechange	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	GUIDE	Guide
CLEAR	Clear	EXIT	Exit
DIMMER	Dimmer	FORMAT	Format
RANDOM	Random	SUBT	Subt
REPEAT	Repeat	TEXT	Text

Original	Rechange