Original		Rechange	
ON	On	Power	
OFF	Off	SHIFT + Power	Shift + Power
VOL	Vol+	+ VOL	Vol+
	Mute	DIMMER MUTE	Mute / Dimmer
CH	CH+	+ CH PAGE	CH+ / Page+
VOL	Vol-	VOL –	Vol-
SURR MODE	Surr Mode	LIST SMART	Smart / List
CH	CH-	CH PAGE –	CH- / Page-
	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
	Left	◀	Left
ENTER	Enter	OK	OK
	Right	▶	Right
	Back	RETURN BACK	Back / Return
	Down	▼	Down
INFO	Info	ANGLE INFO	Info / Angle
IN 1	IN 1	TV 1	1

Original		Rechange	
IN 2	IN 2	DVD 2	2
IN 3	IN 3	CD - STB 3	3
IN 4	IN 4	VIDEO 4	4
IN 5	IN 5	TAPE 5	5
IN 6	IN 6	TUNER 6	6
IN 7	IN 7	AUX - HDD 7	7
IN 8	IN 8	USB 8	8
IN 9	IN 9	BLUETOOTH 9	9
TEST	Test	GOTO TEXT	Text / Goto
IN 0	IN 0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
▶	Play BLS	SLOW ▶	Play / Slow
❚❚	Pause BLS	STEP - FREEZE ❚❚	Pause / Step / Freeze
◀◀	<< BLS	TUNE- ◀◀	<< / Tune-
■	Stop BLS	HOLD ■	Stop / Hold
▶▶	>> BLS	TUNE+ ▶▶	>> / Tune+

Original	Rechange	Original	Rechange
CENT Channel Volume Cent -	SHIFT + ◀ Shift + Left		
CHANNEL Channel Volume Cent+	SHIFT + ▶ Shift + Right		
SUB Channel Volume	SHIFT + ▼ Shift + Down		
SUB Channel Volume	SHIFT + ▲ Shift + Up		
SURR Channel Volume Surr-	SHIFT + CH PAGE − Shift + CH- /		
SURR Channel Volume Surr+	SHIFT + + CH PAGE Shift + CH+ /		
HGT Channel Volume	SHIFT + VOL − Shift + Vol-		
HGT Channel Volume	SHIFT + + VOL Shift + Vol+		