Original		Rechange	
RECEIVER	Power Recei ver		Power
ENTER	Ent er Recei ver	OK	Ok
	Up Recei ver		Up
	Down Recei ver		Down
	Ri ght Recei ver		Ri ght
	Lef t Recei ver		Lef t
RETURN	Ret urn Recei ver	RETURN BACK	Back
Q SETUP	Q/ Set up Recei ver	HOME SMART	Smart
AUDIO HOME	Home/ Audi o	APP MEDIA	Medi a
PLAY	Pl ay Recei ver	PLAY MODE	Pl ay
	I << Recei ver		I <<
	>>I Recei ver		>>I
	<< Recei ver		<<
	>> Recei ver		>>
	Pause Recei ver		Pause
	St op Recei ver		St op
1	1 Recei ver	1	1

Original		Rechange	
2	2 Recei ver	2	2
3	3 Recei ver	3	3
4	4 Recei ver	4	4
5	5 Recei ver	5	5
6	6 Recei ver	6	6
7	7 Recei ver	7	7
8	8 Recei ver	8	8
9	9 Recei ver	9	9
11 0	0/ 11 Recei ver	0	0
--/-- 10 +10 D.TUN DIMMER	+10/ - - / - - 10/ Di mm er/ D. Tun Recei ve	SHIFT + -/-- GUIDE	Shi f t + Gui de
12 CLR SLEEP	CLR/ Sl eep/ 12 Recei ver	FAV PRE-CH	Pr e Ch
SEARCH MOVIE/TV A	Mov i e Tv/ Red/ Sear ch	A	Red
REPEAT MUSIC B	Musi c/ Gr een/ Repe at Recei ver	B	Gr een
RANDOM GAME C	Game/ Yel l ow/ Ran dom Recei ver	C	Yel l ow
MODE STEREO D	St er eo/ Bl ue/ Mode Recei ver	D	Bl ue
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL –	Vol -

Original		Rechange	
CH+	CH Disc/Album+ Receiver	CH +	Ch +
CH-	CH Disc/Album- Receiver	CH -	Ch -
TV	Power Tv	SHIFT + Power	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH+	CH+ Tv	SHIFT + CH +	Shift + Ch +
CH-	CH- Tv	SHIFT + CH -	Shift + Ch -
	Up Tv	SHIFT + ▲	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT + ▼	Shift + Down
	Right Tv	SHIFT + ▶	Shift + Right
	Left Tv	SHIFT + ◀	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Q/Setup Tv	SHIFT + HOME SMART	Shift + Smart
SEARCH MOVIE/TV A	Red Tv	SETTINGS OPT	Options
REPEAT MUSIC B	Green Tv	SOUND DUAL	Dual

Original		Rechange	
RANDOM GAME C	Yellow Tv	AD SUBT	Subt
MODE STEREO D	Blue Tv	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10 Tv	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual
VOL	Vol - Tv	SHIFT + SETTINGS OPT	Shift + Options
AUX	AUX	REPEAT TEXT	Text

Original		Rechange	
TV/CD	TV/ CD	PICTURE FORMAT	For mat
CBL/SAT	CBL/ SAT	ECO 3D	3D
FM	FM	SHIFT + AD SUBT	Shi f t + Subt
NET	NET	SHIFT + APP MEDIA	Shi f t + Medi a
PC	PC	SHIFT + SEARCH TV/R	Shi f t + TV/ R
BD/DVD	BD/ DVD	SHIFT + REPEAT TEXT	Shi f t + Text
USB	USB	SHIFT + TIMER AV	Shi f t + AV

Original	Rechange

Original		Rechange	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Rechange	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search		Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD		Green
RANDOM GAME C	Game/Yellow/Random BD/DVD		Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD		Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tuner Dimmer BD/DVD	--/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original	Rechange
CBL/SAT	REPEAT TEXT — Text
Vol + Receiver	+ VOL — Vol +
Vol - Receiver	VOL − — Vol -
SOURCE Power CBL/SAT	SHIFT + Power — Shift + Power
CH Disc/Album+ CBL/SAT	+ CH — Ch +
CH Disc/Album- CBL/SAT	CH − — Ch -
MENU Menu/Prev CH CBL/SAT	SHIFT + TOP MENU MENU — Shift + Menu
TOP MENU Top Menu/Guide CBL/SAT	SHIFT + SETTINGS OPT — Shift + Options
RETURN Return CBL/SAT	SHIFT + RETURN BACK — Shift + Back
Q/Setup	SHIFT + HOME SMART — Shift + Smart
Up CBL/SAT	SHIFT + ▲ — Shift + Up
ENTER Enter CBL/SAT	SHIFT + OK — Shift + Ok
Down CBL/SAT	SHIFT + ▼ — Shift + Down
Right CBL/SAT	SHIFT + ▶ — Shift + Right
Left CBL/SAT	SHIFT + ◀ — Shift + Left
Pause CBL/SAT	SHIFT + ❚❚ — Shift + Pause
Stop CBL/SAT	SHIFT + ■ — Shift + Stop

Original	Rechange
<< CBL/SAT	SHIFT + CH − — Shift + Ch -
>> CBL/SAT	SHIFT + + CH — Shift + Ch +
PLAY Play CBL/SAT	ECO 3D — 3D
SEARCH MOVIE/TV A Movie Tv/Red/Search	SOUND DUAL — Dual
REPEAT MUSIC B Music/Green/Repeat CBL/SAT	AD SUBT — Subt
RANDOM GAME C Game/Yellow/Random CBL/SAT	TIMER AV — AV
MODE STEREO D Stereo/Blue/Mode CBL/SAT	PICTURE FORMAT — Format
1 CBL/SAT	SHIFT + 1 — Shift + 1
2 CBL/SAT	SHIFT + 2 — Shift + 2
3 CBL/SAT	SHIFT + 3 — Shift + 3
4 CBL/SAT	SHIFT + 4 — Shift + 4
5 CBL/SAT	SHIFT + 5 — Shift + 5
6 CBL/SAT	SHIFT + 6 — Shift + 6
7 CBL/SAT	SHIFT + 7 — Shift + 7
8 CBL/SAT	SHIFT + 8 — Shift + 8
9 CBL/SAT	SHIFT + 9 — Shift + 9
11 0 0/11 CBL/SAT	SHIFT + 0 — Shift + 0

Original	Rechange	Original	Rechange
BD/DVD	SEARCH TV/R — TV/ R		

Original		Rechange	
SOURCE	Power TV/CD		Power
CH DISC +	CH/Disc+ TV/CD	CH +	Ch +
ALBUM −	CH/Disc TV/CD	CH −	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
⏮	I<< TV/CD	⏮	I<<
⏭	>>I TV/CD	⏭	>>I
◀◀	<< TV/CD	◀◀	<<
▶▶	>> TV/CD	▶▶	>>
PLAY	Play TV/CD	PLAY MODE ▶	Play
II	Pause TV/CD	II	Pause

Original		Rechange	
■	Stop TV/CD	■	Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

TV/CD

Original	Rechange	Original	Rechange
VOL + Recei ver	VOL + Vol +		
VOL - Recei ver	VOL − Vol -		
TV/CD TV/ CD	SEARCH TV/R TV/ R		

Original		Rechange	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL +	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Original		Rechange	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
11 0	0/11 Zone 2	0	0

Original	Rechange	Original	Rechange
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		