| Original | | Rechange | |
|---|---|---|---|
| STANDBY/ON | Power Receiver | | Power |
| VCR/DVR | 1 | TV 1 | 1 |
| VCR/DVR | VCR / DVR | SHIFT + VIDEO 4 | Shift + 4 |
| CBL/SAT | 2 | DVD 2 | 2 |
| CBL/SAT | CBL / SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| 3 | 3 | CD - STB 3 | 3 |
| AUX | 4 | VIDEO 4 | 4 |
| AUX | AUX | SHIFT + AUX - HDD 7 | Shift + 7 |
| MULTI CH | 5 | TAPE 5 | 5 |
| MULTI CH | Multi CH | SHIFT + TV 1 | Shift + 1 |
| DVD | 6 | TUNER 6 | 6 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TAPE | 7 | AUX - HDD 7 | 7 |
| TAPE | TAPE | SHIFT + TAPE 5 | Shift + 5 |
| TUNER | 8 | USB 8 | 8 |
| TUNER | TUNER | SHIFT + TUNER 6 | Shift + 6 |
| CD | 9 | BLUETOOTH 9 | 9 |

| Original | | Rechange | |
|---|---|---|---|
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| D.TUN | D. TUN | LIST SMART | Smart / List |
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| DIMMER | 0 | HDMI - SAT 0 | 0 |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| CH DISC ALBUM | CH+ | CH PAGE + | CH+ / Page+ |
| VOL | Vol + | VOL + | Vol + |
| CH DISC ALBUM | CH- | CH PAGE - | CH- / Page- |
| VOL | Vol - | VOL - | Vol - |
| GUIDE TOP MENU SP A/B | SP A/B | ANGLE INFO | Info / Angle |
| | Up | | Up |
| PREVIOUS MENU MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| PLAYLIST/CAT | Left | | Left |
| ENTER | Enter | OK | OK |
| PLAYLIST/CAT | Right | | Right |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Down | | Down |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| RETURN Return | RETURN BACK Back / Return | L NIGHT DVD L. Night | HOME MENU Menu / Home |
| Pause / Play Rev | STEP-FREEZE Pause / Step / Freeze | CINE FLTR HDD Cine FLTR | TOP MENU D.MENU D. Menu / Top |
| Play | SLOW Play / Slow | | |
| Stop | HOLD Stop / Hold | | |
| << | TUNE- << / Tune- | | |
| >> | TUNE+ >> / Tune+ | | |
| I << | PRESET- I << / Preset- | | |
| >>I | PRESET+ >>I / Preset+ | | |
| STEREO Stereo | LANG I/II AUDIO Audio / Lang I/II | | |
| SURROUND Surround | SURROUND Eject / Surround | | |
| < Listening Mode | SHIFT + PRESET- Shift + I << / Preset- | | |
| Listening Mode > | SHIFT + PRESET+ Shift + >>I / Preset+ | | |
| AUDIO TEST TONE Test Tone | NETFLIX SEARCH Red / Netflix / Search | | |
| SUBTITLE CH SEL CH Sel | APP REPEAT Green / APP / Repeat | | |
| RANDOM LEVEL- Level - | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| REPEAT LEVEL+ Level + | Prime Video RANDOM Blue / Prime Video / Random | | |
| DISPLAY Display | MEDIA DISPLAY Display / Media | | |

| Original | | Rechange | |
|---|---|---|---|
| STANDBY/ON | Power | | Power |
| VCR/DVR | 1 | TV 1 | 1 |
| CBL/SAT | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| AUX | 4 | VIDEO 4 | 4 |
| MULTI CH | 5 | TAPE 5 | 5 |
| DVD | 6 | TUNER 6 | 6 |
| TAPE | 7 | AUX-HDD 7 | 7 |
| TUNER | 8 | USB 8 | 8 |
| CD | 9 | BLUETOOTH 9 | 9 |
| 10 | +10/10/-/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 11 DIMMER | 0/11 | HDMI-SAT 0 | 0 |
| CLR 12 SLEEP | CLR/12/Sleep | TIMER SLEEP | Sleep / Timer |
| CLR 12 SLEEP | CLR/12/Sleep | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| GUIDE TOP MENU SP A/B | Guide/Top | TOP MENU D.MENU | D.Menu / Top |
| | Up | | Up |
| PREVIOUS MENU MUTING | Previous Menu/Muting | HOME MENU | Menu / Home |

| Original | | Rechange | |
|---|---|---|---|
| PLAYLIST/CAT | Left/Playlist/Ca | | Left |
| ENTER | Enter | OK | OK |
| PLAYLIST/CAT | Right/Playlist/C | | Right |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |
| | Stop | HOLD | Stop / Hold |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| STEREO | Stereo | TITLE SOUND | Sound / Title |
| SURROUND | Surround | SURROUND | Eject / Surround |
| | < Listening Mode | SHIFT + PRESET- | Shift + I<< / Preset- |
| | Listening Mode > | SHIFT + PRESET+ | Shift + >>I / Preset+ |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| AUDIO / TEST TONE | Audio | LANG I/II / AUDIO | Audio / Lang I/II | | |
| SUBTITLE / CH SEL | Subtitle | EQ / SUBTITLE | Subtitle / EQ | | |
| RANDOM / LEVEL- | Level - / Random | Prime Video / RANDOM | Blue / Prime Video / Random | | |
| REPEAT / LEVEL+ | Level + / Repeat | APP / REPEAT | Green / APP / Repeat | | |
| DISPLAY | Display | MEDIA / DISPLAY | Display / Media | | |
| PLAY MODE / VCR | Play Mode VCR | SHIFT + VIDEO 4 | Shift + 4 | | |
| L NIGHT / DVD | Play Mode DVD | SHIFT + DVD 2 | Shift + 2 | | |
| CINE FLTR / HDD | Play Mode HDD | SHIFT + AUX - HDD 7 | Shift + 7 | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| STANDBY/ON | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| +10/10/-/-- | | GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI-SAT 0 | 0 |
| CLR/12/Sleep | | TIMER SLEEP | Sleep / Timer |
| CLR/12/Sleep | | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| Disc/Album | | CH PAGE + | CH+ / Page+ |
| Vol + | | VOL + | Vol + |
| Disc/Album CH- | | CH PAGE - | CH- / Page- |

| Original | | Rechange | |
|---|---|---|---|
| VOL | Vol - | VOL - | Vol - |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |
| | Stop | HOLD | Stop / Hold |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| STEREO | Stereo | LANG I/II AUDIO | Audio / Lang I/II |
| SURROUND | Surround | SURROUND | Eject / Surround |
| | < Listening Mode | SHIFT + PRESET- | Shift + I<< / Preset- |
| | Listening Mode > | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| RANDOM LEVEL- | Level -/Random | Prime Video RANDOM | Blue / Prime Video / Random |
| REPEAT LEVEL+ | Level +/Repeat | APP REPEAT | Green / APP / Repeat |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |

| Original | | Rechange | |
|---|---|---|---|
| STANDBY/ON | Standby / On | | Power |
| VCR/DVR | VCR/DVR | VIDEO 4 | 4 |
| CBL/SAT | CBL/SAT | HDMI - SAT 0 | 0 |
| AUX | AUX | AUX - HDD 7 | 7 |
| MULTI CH | Multi CH | TV 1 | 1 |
| DVD | DVD | DVD 2 | 2 |
| TAPE | Tape | TAPE 5 | 5 |
| TUNER | Tuner | TUNER 6 | 6 |
| CD | CD | CD - STB 3 | 3 |
| D. TUN | D. Tun | LIST SMART | Smart / List |
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| CLR SLEEP | CLR / Sleep | TIMER SLEEP | Sleep / Timer |
| CLR SLEEP | CLR / Sleep | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| CH DISC ALBUM + | CH Disc | CH PAGE + | CH+ / Page+ |
| VOL | Vol + | VOL + | Vol + |
| CH DISC ALBUM − | CH Disc Album | CH PAGE − | CH- / Page- |
| VOL | Vol - | VOL − | Vol - |

| Original | | Rechange | |
|---|---|---|---|
| | Up | | Up |
| PREVIOUS MENU / MUTING | Muting | DIMMER MUTE | Mute / Dimmer |
| PLAYLIST/CAT | Left/Playlist/Ca | | Left |
| ENTER | Enter | OK | OK |
| PLAYLIST/CAT | Right/Playlist/C | | Right |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| | Rev. Play | STEP - FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |
| | Stop | HOLD | Stop / Hold |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| STEREO | Stereo | LANG I/II AUDIO | Audio / Lang I/II |
| SURROUND | Surround | | Eject / Surround |
| | < Listening Mode | PRESET- | I<< / Preset- |
| | Listening Mode > | PRESET+ | >>I / Preset+ |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| AUDIO TEST TONE Test Tone | NETFLIX SEARCH Red / Netflix / Search | | |
| SUBTITLE CH SEL CH Sel | APP REPEAT Green / APP / Repeat | | |
| RANDOM LEVEL- Level - | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| REPEAT LEVEL+ Level + | Prime Video RANDOM Blue / Prime Video / Random | | |
| DISPLAY Display | MEDIA DISPLAY Display / Media | | |
| L NIGHT DVD L. Night / Play Mode DVD | HOME MENU Menu / Home | | |
| CINE FLTR HDD Cine FLTR / Play Mode HDD | TOP MENU D.MENU D. Menu / Top | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |