Original		Rechange	
ON/STANDBY	On / Standby		Power
1 V1	Input Selector V	TV 1	1
2 V2	Input Selector V	DVD 2	2
3 V3	Input Selector V	CD-STB 3	3
5 MULTI CH	Input Selector Multi CH	TAPE 5	5
6 DVD	Input Selector	TUNER 6	6
7 TAPE	Input Selector	AUX-HDD 7	7
8 TUNER	Input Selector Tuner	USB 8	8
9 CD	Input Selector C	BLUETOOTH 9	9
0 DIMMER	Dimmer	HDMI-SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
GUIDE TOP MENU	Guide/Top	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	SURROUND	Eject / Surround
ENTER	Enter	OK	OK
	Up		Up

Original		Rechange	
	Down		Down
PLAYLIST/CAT+	Right		Right
-PLAYLIST/CAT	Left		Left
	Play	SLOW	Play / Slow
	Rev. Play	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<<	TUNE+	>> / Tune+
	>>	PRESET-	I<< / Preset-
	I<<	TUNE-	<< / Tune-
	>>I	PRESET+	>>I / Preset+
STEREO	Listening Mode Stereo	NETFLIX SEARCH	Red / Netflix / Search
SURROUND	Listening Mode Surround	APP REPEAT	Green / APP / Repeat
	Listening Mode <	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Listening Mode >	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO TEST TONE	Test Tone/Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE CH SEL	CH Sel/Subtitl	EQ SUBTITLE	Subtitle / EQ
RANDOM LEVEL-	Level -/Random	PROGRAM TV/RADIO	TV/Radio / Program

Original	Rechange	Original	Rechange
REPEAT LEVEL+ Level +/ Repeat	SIZE ZOOM Zoom / Size	6 DVD 6 Tv	SHIFT + TUNER 6 Shift + 6
DISPLAY Display	ANGLE INFO Info / Angle	7 TAPE 7 Tv	SHIFT + AUX - HDD 7 Shift + 7
L NIGHT DVD L. Night	LIST SMART Smart / List	8 TUNER 8 Tv	SHIFT + USB 8 Shift + 8
CINE FLTR HDD Cine FLTR	MEDIA DISPLAY Display / Media	9 CD 9 Tv	SHIFT + BLUETOOTH 9 Shift + 9
INPUT Input Tv	SHIFT + RDS AV INPUT Shift + AV / Input / RDS	0 DIMMER 0 Tv	SHIFT + HDMI - SAT 0 Shift + 0
CH DISC ALBUM CH/Disc/Album	CH PAGE + CH+ / Page+	+10 D.TUN +10 Tv	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--
CH DISC ALBUM – CH/Disc/Album-	CH PAGE – CH- / Page-	PREVIOUS MENU MUTING Muting/Previous Menu Tv	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
VOL Vol +	VOL + Vol +	ENTER Enter Tv	SHIFT + OK Shift + OK
VOL Vol -	VOL – Vol -	PLAYLIST/CAT+ Right Tv	SHIFT + Shift + Right
Power Tv/Standby	SHIFT + Shift + Power	PLAYLIST/CAT- Left Tv	SHIFT + Shift + Left
VOL Vol + Tv	SHIFT + VOL + Shift + Vol +	SETUP Setup Tv	TOP MENU D.MENU D. Menu / Top
VOL Vol - Tv	SHIFT + VOL – Shift + Vol -	Up Tv	SHIFT + Shift + Up
1 V1 1 Tv	SHIFT + TV 1 Shift + 1	Down Tv	SHIFT + Shift + Down
2 V2 2 Tv	SHIFT + DVD 2 Shift + 2		
3 V3 3 Tv	SHIFT + CD - STB 3 Shift + 3		
4 V4 4 Tv	SHIFT + VIDEO 4 Shift + 4		
5 MULTI CH 5 Tv	SHIFT + TAPE 5 Shift + 5		

Original		Rechange	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CLR	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home

Original		Rechange	
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT	Right/Playlist/C		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I << / Preset-

Original	Rechange	Original	Rechange
Listening Mode >	SHIFT + PRESET+		
Audio	LANG I/II AUDIO		
Subtitle	EQ SUBTITLE		
Random	Prime Video RANDOM		
Repeat	APP REPEAT		
Display	MEDIA DISPLAY		
Play Mode VCR	FORMAT PICTURE		
DVD	SHIFT + DVD 2		
HDD	SHIFT + AUX - HDD 7		

Shift + >>I / Preset+

Shift + 2

Shift + 7

Original	Rechange	Original	Rechange
On / Standby	Power	Pause	Pause / Step / Freeze
1	1	Play	Play / Slow
2	2	Stop	Stop / Hold
3	3	<<	<< / Tune-
4	4	>>	>> / Tune+
5	5	I <<	I << / Preset-
6	6	>>I	>>I / Preset+
7	7	Stereo	Audio / Lang I/II
8	8	Surround	Eject / Surround
9	9	< Listening Mode	Shift + I << / Preset-
+10/10/-/--	Guide / EPG / -/--	Listening Mode >	Shift + >>I / Preset+
0/11	0	Random	Blue / Prime Video / Random
12	Fav / Marker / PC	Repeat	Green / APP / Repeat
Disc+	CH+ / Page+	Display	Display / Media
Vol +	Vol +		
Disc-	CH- / Page-		
Vol -	Vol -		

Original		Rechange	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CH+	CH+	CH+	CH+ / Page+
CH-	CH-	CH-	CH- / Page-
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze
Play	Play	SLOW	Play / Slow
Stop	Stop	HOLD	Stop / Hold

Original		Rechange	
<<	<<	TUNE-	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
<	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
>	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L NIGHT DVD	L. Night	TIMER SLEEP	Sleep / Timer