Original		Rechange	
STANDBY/ON	On / Standby		Power
1 V1	Input Selector V1	TV 1	1
2 V2	Input Selector V2	VIDEO 4	4
3 V3	Input Selector V3	AUX - HDD 7	7
5 MULTI CH	Input Selector Multi CH	USB 8	8
6 DVD	Input Selector	DVD 2	2
7 TAPE	Input Selector	TAPE 5	5
8 TUNER	Input Selector Tuner	TUNER 6	6
9 CD	Input Selector CD	CD - STB 3	3
0 DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I/⏻	Power Tv	SHIFT + ⏻	Shift + Power
VOL	Vol+ Tv	SHIFT + + VOL	Shift + Vol+
+ CH DISC	CH/Disc/Album	+ CH PAGE	CH+ / Page+
VOL	Vol+	+ VOL	Vol+
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOL	Vol- Tv	SHIFT + VOL −	Shift + Vol-

Original		Rechange	
CH DISC ALBUM −	CH/Disc/Album-	CH PAGE −	CH- / Page-
VOL	Vol-	VOL −	Vol-
GUIDE TOP MENU	Guide/Top	-/-- GUIDE EPG	Guide / EPG / -/--
GUIDE TOP MENU	Guide/Top	TOP MENU D.MENU	D.Menu / Top
▲	Up	▲	Up
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
◄ PLAYLIST	Left	◄	Left
ENTER	Enter	OK	OK
► PLAYLIST	Right	►	Right
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
►	Play	SLOW ▶	Play / Slow
■	Stop	HOLD ■	Stop / Hold
◄◄	<<	TUNE- ◄◄	<< / Tune-
►►	>>	TUNE+ ►►	>> / Tune+

Original	Rechange
I<<	I<< / Preset-
>>I	>>I / Preset+
Listening Mode Stereo	Subtitle / EQ
Listening Mode Surround	Eject / Surround
Listening Mode <	Sound / Title
Listening Mode >	Audio / Lang I/II
Test Tone	Red / Netflix / Search
CH Sel	Green / APP / Repeat
Level-	Yellow / YouTube / Repeat
Level+	Blue / Prime Video / Random
Display	Display / Media
L.Night	Zoom / Size
Cine FLTR	Picture / Format

Original	Rechange

Original		Rechange	
STANDBY/ON	Power		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR SLEEP	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer

Original		Rechange	
PLAYLIST	Left/Playlist/Cat-		Left
ENTER	Enter	OK	OK
PLAYLIST	Right/Playlist/Cat		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
LISTENING SURROUND	Surround	SHIFT + SURROUND	Shift + Eject / Surround
G MODE	< Listening Mode	SHIFT + TITLE SOUND	Shift + Sound / Title
	Listening Mode >	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II

Original		Rechange	
AUDIO / TEST TONE	Audio	LANG I/II / AUDIO	Audio / Lang I/II
SUBTITLE / CH SEL	Subtitle	EQ / SUBTITLE	Subtitle / EQ
RANDOM / LEVEL-	Random	Prime Video / RANDOM	Blue / Prime Video / Random
REPEAT / LEVEL+	Repeat	APP / REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA / DISPLAY	Display / Media
PLAY MODE / VCR	VCR	SHIFT + VIDEO / 4	Shift + 4
PLAY MODE / VCR	Play Mode VCR	FORMAT / PICTURE	Picture / Format
L NIGHT / DVD	DVD	SHIFT + DVD / 2	Shift + 2
CINE FLTR / HDD	HDD	SHIFT + AUX - HDD / 7	Shift + 7

Original	Rechange

Original		Rechange	
STANDBY/ON	On / Standby		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR SLEEP	12	PC FAV MARKER	Fav / Marker / PC
CH DISC ALBUM +	Disc+	CH PAGE +	CH+ / Page+
VOL ▲	Vol+	VOL +	Vol+
CH DISC ALBUM −	Disc-	CH PAGE −	CH- / Page-
VOL ▼	Vol-	VOL −	Vol-

Original		Rechange	
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
►	Play	SLOW ►	Play / Slow
■	Stop	HOLD ■	Stop / Hold
◄◄	<<	TUNE- ◄◄	<< / Tune-
►►	>>	TUNE+ ►►	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
LISTENING SURROUND	Surround	SURROUND ⏏	Eject / Surround
G MODE ◄	< Listening Mode	TITLE SOUND	Sound / Title
►	Listening Mode >	LANG I/II AUDIO	Audio / Lang I/II
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original	Rechange	Original	Rechange
Power	Power	<<	<< / Tune-
1	1	Stereo	Subtitle / EQ
2	2	Surround	Eject / Surround
3	3	< Listening Mode	Sound / Title
4	4	Listening Mode >	Audio / Lang I/II
5	5	Play Mode	D.Menu / Top
6	6	L.Night	Sleep / Timer
7	7		
8	8		
9	9		
+10/10/-/--	Guide / EPG / -/--		
0/11	0		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
Stop	Stop / Hold		